

ICC2 FEATURE REMINDER

FEATURE	HOW TO ACCESS
Programmable Sensor Override	Hold -, turn to Start Times
Cycle and Soak	Hold +, turn to Run Times Press PRG to set Soak
Delay Between Stations	Hold -, turn to Run Times
Hide Programs	Hold -, turn to Water Days
Solar Sync [®] Delay	Hold +, turn to Solar Sync
Clik Delay	Hold +, turn to System Off

FEATURE	HOW TO ACCESS
Flow Setup	Hold + and turn to Pump
Flow Monitor	Hold - and turn to Pump
Manual Program Run	Hold ▶ , press PRG to select
Test Program	Hold PRG for 3 seconds
Easy Retrieve™ Memory	Press + and PRG to Save Press - and PRG to Restore
QuickCheck™	Press + , - , ◀ , ▶ together Press + to begin check