

# ICC2 FEATURE REMINDER

FEATURE	HOW TO ACCESS
Programmable Sensor Override	Hold -, turn to Start Times
Cycle and Soak	Hold +, turn to Run Times Press <b>PRG</b> to set Soak
Delay Between Stations	Hold -, turn to Run Times
Hide Programs	Hold -, turn to Water Days
Solar Sync® Delay	Hold +, turn to Solar Sync
Clik Delay	Hold +, turn to System Off

FEATURE	HOW TO ACCESS
Flow Setup	Hold <b>+</b> and turn to Pump
Flow Monitor	Hold <b>-</b> and turn to Pump
Manual Program Run	Hold <b>▶</b> , press <b>PRG</b> to select
Test Program	Hold <b>PRG</b> for 3 seconds
Easy Retrieve® Memory	Press <b>+</b> and <b>PRG</b> to Save Press <b>-</b> and <b>PRG</b> to Restore
QuickCheck™	Press <b>+</b> , <b>-</b> , <b>◀</b> , <b>▶</b> together Press <b>+</b> to begin check