IRRIGATION HYDRAULICS

Student's Manual

-9

7 VM

Hunter[®] Irrigation Design Education Module

Table of Contents

How Does Hydraulics Affect an Irrigation System. 2 Important facts to learn. 2 Water Pressure 3 How pressure is created by the weight of water. 4 Important Facts. 5 Does the shape or size of the container make a difference? 6 What does this mean in irrigation system design? 7 Static and dynamic pressure 8 Factors affecting static pressure. 10 Water Movement in Irrigation Systems 12 Factors Affecting Dynamic Pressure. 12 Friction loss in pipe 12 Velocity. 13 Inside diameter 13 Roughness 14 Length. 15 Use of Pressure Loss Charts. 16 What the charts are used for 18 Sample problems: using friction loss charts 19 Determining Dressure Losses in pipes 20 Sample problems: dynamic pressure 23 Factors Affecting Flow in an Irrigation System 23 Factors Infittings. 26 Velocity head. 26 Friction loss in fittings. 26 <	Introduction	2
Important facts to learn. 2 Water Pressure 3 How pressure is created by the weight of water. 4 Important Facts. 5 Does the shape or size of the container make a difference? 6 What does this mean in irrigation system design? 7 Static and dynamic pressure. 8 Sample problems: determining static pressure. 8 Sample problems: determining static pressure. 10 Water Movement in Irrigation Systems 12 Factors Affecting Dynamic Pressure. 12 Friction loss in pipe. 12 Velocity. 13 Inside diameter 13 Roughness 14 Length. 15 Use of Pressure Loss Charts. 16 What the charts are used for 18 Determining pressure loss in pipes with friction loss charts 18 Sample problems: using friction loss charts. 19 Determining Dynamic Pressure Losses in Pipe 20 Sample problems: dynamic pressure 21 General Principles of Water Flow in an Irrigation System 23 How the pressure available at the source affects flow	How Does Hydraulics Affect an Irrigation System	2
How pressure is created by the weight of water. 4 Important Facts. 5 Does the shape or size of the container make a difference? 6 What does this mean in irrigation system design? 7 Static and dynamic pressure. 8 Factors affecting static pressure. 8 Sample problems: determining static pressure. 10 Water Movement in Irrigation Systems 12 Friction loss in pipe 12 Velocity 13 Inside diameter 13 Roughness 14 Length. 15 Use of Pressure Loss Charts. 16 What the charts are used for 18 Determining pressure loss in pipes with friction loss charts 19 Determining Dynamic Pressure Losses in Pipe 20 Sample problems: dynamic pressure 21 General Principles of Water Flow in an Irrigation System 23 How the pressure losses from the source affects flow. 24 How pressure losses from the source to the outlet affect flow 25 Friction loss in pipe. 26 Velocity head. 26 Entrance loss 26<		
Important Facts5Does the shape or size of the container make a difference?6What does this mean in irrigation system design?7Static and dynamic pressure8Factors affecting static pressure8Sample problems: determining static pressure10Water Movement in Irrigation Systems12Factors Affecting Dynamic Pressure12Friction loss in pipe12Velocity13Inside diameter13Roughness14Length15Use of Pressure Loss Charts16What the charts are used for18Determining pressure loss in pipes with friction loss charts18Sample problems: using friction loss charts18Sample problems: dynamic pressure20Sample problems: dynamic pressure23Factors Affecting Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System24How the pressure losses from the source offects flow24How the pressure loss in fittings26Friction loss in fittings26Entrance loss26Entrance loss26Entrance loss26Entrance loss28Using smaller pipe does not increase the flow28Using smaller pipe does not increase the flow28Using smaller pipe does not increases the flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pr	Water Pressure	3
Important Facts5Does the shape or size of the container make a difference?6What does this mean in irrigation system design?7Static and dynamic pressure8Factors affecting static pressure8Sample problems: determining static pressure10Water Movement in Irrigation Systems12Factors Affecting Dynamic Pressure12Friction loss in pipe12Velocity13Inside diameter13Roughness14Length15Use of Pressure Loss Charts16What the charts are used for18Determining pressure loss in pipes with friction loss charts18Sample problems: using friction loss charts18Sample problems: dynamic pressure20Sample problems: dynamic pressure23Factors Affecting Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System24How the pressure losses from the source offects flow24How the pressure loss in fittings26Friction loss in fittings26Entrance loss26Entrance loss26Entrance loss26Entrance loss28Using smaller pipe does not increase the flow28Using smaller pipe does not increase the flow28Using smaller pipe does not increases the flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pr	How pressure is created by the weight of water	4
What does this mean in irrigation system design? 7 Static and dynamic pressure 8 Factors affecting static pressure. 10 Water Movement in Irrigation Systems 12 Factors Affecting Dynamic Pressure. 12 Friction loss in pipe 12 Velocity. 13 Inside diameter 13 Roughness 14 Length. 15 Use of Pressure Loss Charts. 16 What the charts are used for 18 Determining pressure loss in pipes with friction loss charts. 19 Determining Dynamic Pressure Losses in Pipe 20 Sample problems: using friction loss charts. 19 Determining Dynamic Pressure Losses in Pipe 20 Sample problems: dynamic pressure 21 General Principles of Water Flow in an Irrigation System 23 Factors Affecting Flow in an Irrigation System 23 How the pressure available at the source affects flow 24 How pressure losses from the source to the outlet affect flow 25 Friction loss in fittings 26 Velocity head. 26 Entrance loss	· · ·	
What does this mean in irrigation system design? 7 Static and dynamic pressure 8 Factors affecting static pressure. 10 Water Movement in Irrigation Systems 12 Factors Affecting Dynamic Pressure. 12 Friction loss in pipe 12 Velocity. 13 Inside diameter 13 Roughness 14 Length. 15 Use of Pressure Loss Charts. 16 What the charts are used for 18 Determining pressure loss in pipes with friction loss charts. 19 Determining Dynamic Pressure Losses in Pipe 20 Sample problems: using friction loss charts. 19 Determining Dynamic Pressure Losses in Pipe 20 Sample problems: dynamic pressure 21 General Principles of Water Flow in an Irrigation System 23 Factors Affecting Flow in an Irrigation System 23 How the pressure available at the source affects flow 24 How pressure losses from the source to the outlet affect flow 25 Friction loss in fittings 26 Velocity head. 26 Entrance loss	Does the shape or size of the container make a difference?	6
Factors affecting static pressure8Sample problems: determining static pressure10Water Movement in Irrigation Systems.12Factors Affecting Dynamic Pressure12Friction loss in pipe12Velocity13Inside diameter.13Roughness.14Length15Use of Pressure Loss Charts16What the charts are used for.18Determining pressure loss in pipes with friction loss charts.18Sample problems: using friction loss charts.19Determining Dynamic Pressure Losses in Pipe.20Sample problems: dynamic pressure.21General Principles of Water Flow in an Irrigation System.23Factors Affecting Flow in an Irrigation System.23How the pressure losses from the source affects flow.24How pressure losses from the source to the outlet affect flow.25Friction loss in pipe.26Velocity head.26Entrance loss.26The relationship between pressure and flow.28Using smaller pipe does not increase the flow.28Using smaller pipe does not increase the flow.28Using smaller pipe does not increase the flow.29What Happens When the Water Reaches a Sprinkler Head?.31Flow and Pressure Loss in a Typical Sprinkler System.33Sample problems: dynamic pressure losses in.36Pressure Loss in Fittings.40Important Definitions.41Answers to Sample Pro		
Sample problems: determining static pressure10Water Movement in Irrigation Systems12Factors Affecting Dynamic Pressure.12Friction loss in pipe12Velocity.13Inside diameter13Roughness14Length.15Use of Pressure Loss Charts16What the charts are used for18Determining pressure loss in pipes with friction loss charts18Sample problems: using friction loss charts19Determining Dynamic Pressure Losses in Pipe20Sample problems: dynamic pressure21General Principles of Water Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System23How the pressure available at the source affects flow24How pressure losses from the source to the outlet affect flow25Friction loss in pipe26Velocity head26Entrance loss26Velocity head28Increasing pressure and flow28Using smaller pipe does not increase the flow28Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42 <tr< td=""><td></td><td></td></tr<>		
Water Movement in Irrigation Systems12Factors Affecting Dynamic Pressure12Friction loss in pipe12Velocity13Inside diameter13Roughness14Length15Use of Pressure Loss Charts.16What the charts are used for18Determining pressure loss in pipes with friction loss charts18Sample problems: using friction loss charts19Determining Dynamic Pressure Losses in Pipe20Sample problems: dynamic pressure21General Principles of Water Flow in an Irrigation System23How the pressure available at the source affects flow24How the pressure losses from the source to the outlet affect flow25Friction loss in pipe.26Friction loss in pipe does not increase the flow28Using smaller pipe does not increase the flow28Using smaller pipe does not increase the flow28Using smaller pipe does not increase the flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		
Factors Affecting Dynamic Pressure 12 Friction loss in pipe 12 Velocity 13 Inside diameter 13 Roughness 14 Length 15 Use of Pressure Loss Charts. 16 What the charts are used for 18 Determining pressure loss in pipes with friction loss charts 18 Sample problems: using friction loss charts 19 Determining Dynamic Pressure Losses in Pipe 20 Sample problems: dynamic pressure 21 General Principles of Water Flow in an Irrigation System 23 How the pressure available at the source affects flow 24 How the pressure available at the source affect flow 25 Friction loss in pipe. 26 Velocity head 26 Entrance loss 26 The relationship between pressure and flow 28 Using smaller pipe does not increase the flow 28 Using smaller pipe does not increase the flow 28 Using smaller pipe does not increase the flow 29 What Happens When the Water Reaches a Sprinkler Head? 31 Flow and Pressure Loss in a T	Sample problems: determining static pressure	. 10
Friction loss in pipe12Velocity13Inside diameter13Roughness14Length15Use of Pressure Loss Charts16What the charts are used for18Determining pressure loss in pipes with friction loss charts19Determining Dynamic Pressure Losses in Pipe20Sample problems: using friction loss charts19Determining Dynamic Pressure Losses in Pipe20Sample problems: dynamic pressure21General Principles of Water Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System23How the pressure losses from the source affects flow24How the pressure losses from the source affects flow24How pressure losses from the source to the outlet affect flow25Friction loss in pipe26Velocity head26Entrance loss26The relationship between pressure and flow28Using smaller pipe does not increase the flow28Using smaller pipe does not result in higher pressure28Using smaller pipe does not result in higher pressure31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46	Water Movement in Irrigation Systems	. 12
Velocity13Inside diameter13Roughness14Length.15Use of Pressure Loss Charts.16What the charts are used for18Determining pressure loss in pipes with friction loss charts.18Sample problems: using friction loss charts.19Determining Dynamic Pressure Losses in Pipe20Sample problems: dynamic pressure.21General Principles of Water Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System23How the pressure available at the source affects flow24How pressure losses from the source to the outlet affect flow25Friction loss in fittings26Velocity head26Entrance loss26The relationship between pressure and flow28Increasing pressure at the source increases the flow28Using smaller pipe does not increase the flow28Using smaller pipe does not increase the flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46	Factors Affecting Dynamic Pressure	. 12
Inside diameter13Roughness14Length.15Use of Pressure Loss Charts.16What the charts are used for18Determining pressure loss in pipes with friction loss charts18Sample problems: using friction loss charts19Determining Dynamic Pressure Losses in Pipe20Sample problems: dynamic pressure in Pipe20Sample problems: dynamic pressure21General Principles of Water Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System23How the pressure available at the source affects flow24How pressure losses from the source to the outlet affect flow25Friction loss in pipe26Friction loss in fittings26Velocity head26Entrance loss26The relationship between pressure and flow28Using smaller pipe does not increases the flow28Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46	Friction loss in pipe	. 12
Roughness14Length.15Use of Pressure Loss Charts.16What the charts are used for18Determining pressure loss in pipes with friction loss charts18Sample problems: using friction loss charts19Determining Dynamic Pressure Losses in Pipe20Sample problems: dynamic pressure.21General Principles of Water Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System23How the pressure available at the source affects flow24How pressure losses from the source to the outlet affect flow25Friction loss in pipe26Friction loss in fittings26Velocity head26Entrance loss26Using smaller pipe does not increase the flow28Using smaller pipe does not increase the flow28Using smaller pipe does not increase the flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in36Pressure Loss in Fittings40Summary.40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		
Length		
Use of Pressure Loss Charts.16What the charts are used for18Determining pressure loss in pipes with friction loss charts19Determining Dynamic Pressure Losses in Pipe20Sample problems: dynamic pressure21General Principles of Water Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System23How the pressure available at the source affects flow24How pressure losses from the source to the outlet affect flow25Friction loss in pipe26Velocity head26Entrance loss26The relationship between pressure and flow28Increasing pressure at the source increases the flow28Using smaller pipe does not increase the flow28Using smaller pipe does not increase the flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		
What the charts are used for18Determining pressure loss in pipes with friction loss charts18Sample problems: using friction loss charts19Determining Dynamic Pressure Losses in Pipe20Sample problems: dynamic pressure21General Principles of Water Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System23How the pressure available at the source affects flow24How pressure losses from the source to the outlet affect flow25Friction loss in pipe26Friction loss in fittings26Velocity head26Entrance loss26The relationship between pressure and flow28Using smaller pipe does not increase the flow28Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46	6	
Determining pressure loss in pipes with friction loss charts18Sample problems: using friction loss charts19Determining Dynamic Pressure Losses in Pipe20Sample problems: dynamic pressure21General Principles of Water Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System23How the pressure available at the source affects flow24How pressure losses from the source to the outlet affect flow25Friction loss in pipe26Friction loss in fittings26Velocity head26Entrance loss26The relationship between pressure and flow28Increasing pressure at the source increases the flow28Using smaller pipe does not increase the flow28Using smaller pipe does not result in higher pressure21How the size of the outlet affects flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		
Sample problems: using friction loss charts19Determining Dynamic Pressure Losses in Pipe20Sample problems: dynamic pressure21General Principles of Water Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System23How the pressure available at the source affects flow24How pressure losses from the source to the outlet affect flow25Friction loss in pipe26Friction loss in fittings26Velocity head26Entrance loss26The relationship between pressure and flow28Using smaller pipe does not increase the flow28Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		
Determining Dynamic Pressure Losses in Pipe20Sample problems: dynamic pressure21General Principles of Water Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System23How the pressure available at the source affects flow24How pressure losses from the source to the outlet affect flow25Friction loss in pipe26Friction loss in fittings26Velocity head26Entrance loss26The relationship between pressure and flow28Using smaller pipe does not increase the flow28Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in landscape irrigation systems36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		
Sample problems: dynamic pressure21General Principles of Water Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System23How the pressure available at the source affects flow24How pressure losses from the source to the outlet affect flow25Friction loss in pipe26Friction loss in fittings26Velocity head26Entrance loss26The relationship between pressure and flow28Increasing pressure at the source increases the flow28Using smaller pipe does not increase the flow28Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in landscape irrigation systems36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46	Sample problems: using friction loss charts	. 19
General Principles of Water Flow in an Irrigation System23Factors Affecting Flow in an Irrigation System23How the pressure available at the source affects flow24How pressure losses from the source to the outlet affect flow25Friction loss in pipe26Friction loss in fittings26Velocity head26Entrance loss26The relationship between pressure and flow28Increasing pressure at the source increases the flow28Using smaller pipe does not increase the flow28Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in landscape irrigation systems36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		
Factors Affecting Flow in an Irrigation System.23How the pressure available at the source affects flow.24How pressure losses from the source to the outlet affect flow25Friction loss in pipe.26Friction loss in fittings.26Velocity head.26Entrance loss26The relationship between pressure and flow28Increasing pressure at the source increases the flow.28Using smaller pipe does not increase the flow.28Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46	Sample problems: dynamic pressure	. 21
How the pressure available at the source affects flow24How pressure losses from the source to the outlet affect flow25Friction loss in pipe26Friction loss in fittings26Velocity head26Entrance loss26The relationship between pressure and flow28Increasing pressure at the source increases the flow28Using smaller pipe does not increase the flow28Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46	General Principles of Water Flow in an Irrigation System	23
How the pressure available at the source affects flow24How pressure losses from the source to the outlet affect flow25Friction loss in pipe26Friction loss in fittings26Velocity head26Entrance loss26The relationship between pressure and flow28Increasing pressure at the source increases the flow28Using smaller pipe does not increase the flow28Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46	Factors Affecting Flow in an Irrigation System	23
Friction loss in pipe		
Friction loss in fittings.26Velocity head.26Entrance loss26The relationship between pressure and flow28Increasing pressure at the source increases the flow.28Using smaller pipe does not increase the flow.28Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow.29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46	How pressure losses from the source to the outlet affect flow	25
Velocity head.26Entrance loss26The relationship between pressure and flow28Increasing pressure at the source increases the flow.28Using smaller pipe does not increase the flow.28Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow.29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in landscape irrigation systems.36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		
Entrance loss26The relationship between pressure and flow28Increasing pressure at the source increases the flow28Using smaller pipe does not increase the flow28Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in landscape irrigation systems36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46	e	
The relationship between pressure and flow28Increasing pressure at the source increases the flow28Using smaller pipe does not increase the flow28Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in landscape irrigation systems36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		
Increasing pressure at the source increases the flow.28Using smaller pipe does not increase the flow.28Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow.29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in landscape irrigation systems.36Pressure Loss in Fittings40Summary.40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		
Using smaller pipe does not increase the flow		
Using smaller pipe does not result in higher pressure28How the size of the outlet affects flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in landscape irrigation systems36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46	÷ .	
How the size of the outlet affects flow29What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in landscape irrigation systems36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		
What Happens When the Water Reaches a Sprinkler Head?31Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in landscape irrigation systems36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		
Flow and Pressure Loss in a Typical Sprinkler System33Sample problems: dynamic pressure losses in landscape irrigation systems36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		
Sample problems: dynamic pressure losses in landscape irrigation systems		
landscape irrigation systems.36Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		. 33
Pressure Loss in Fittings40Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		26
Summary40Important Definitions41Answers to Sample Problems42Friction Loss Charts46		
Important Definitions41Answers to Sample Problems42Friction Loss Charts46	Pressure Loss in Fittings	. 40
Answers to Sample Problems	Summary	. 40
Answers to Sample Problems	Important Definitions	41
Friction Loss Charts	<u>^</u>	
	*	



Introduction

Hydraulics is defined as a branch of science that deals with the effects of water or other liquids in motion. In this manual we will study characteristics of water both in motion and at rest. The emphasis will be on the relationships between flow, velocity, and pressure. With this knowledge we will be able to determine pressure losses in pipe and fittings and pressures at various points in an irrigation system.

A knowledge of the basic principles of irrigation hydraulics is essential to designing and maintaining an economical and efficient irrigation system. Understanding the principles outlined in this manual will lead to irrigation systems that have a more uniform distribution of water and cost less to install and maintain.

How Does Hydraulics Affect an Irrigation System?

Water pressure in an irrigation system will affect the performance of the sprinklers. If the system is designed correctly there will be enough pressure throughout the system for all the sprinklers to operate properly. Maintaining this pressure in the system will help to ensure the most uniform coverage possible. While a consistent pressure is the primary goal, it is important to achieve this at the lowest cost. With a knowledge of hydraulics, it is possible to design a system using the smallest and therefore least expensive components while conserving sufficient pressure for optimum system performance.

Important facts to learn

- 1) The effect of static and dynamic pressure on sprinkler operation.
- 2) The forces that cause pressure to increase or decrease in an irrigation system.
- 3) The relationships between pressure, velocity, and flow in an irrigation system.
- 4) How to calculate static and dynamic pressures at various points in an irrigation system.
- 5) How to determine dynamic pressure losses in pipe and fittings.

Water Pressure

Water pressure in irrigation systems is created in two ways:

- 1) by using the weight of water (such as with a water tower) to exert the force necessary to create pressure in the system or
- 2) by the use of a pump (a mechanical pressurization).

In many municipal water delivery systems both of these methods may be used to create the water pressure we have at our homes and businesses. Water tanks use gravity to create pressure. These tanks are located on a mountain top, tower, or roof top. Because these storage tanks are located above the homes they serve, the weight of the water creates pressure in the pipes leading to those homes.

A "booster" pump is used to increase the pressure where the elevation of the water storage tank is not high enough above the home to provide sufficient pressure. In other areas, the water source may be a well, lake, or canal with a pump generating the pressure.

In this manual, we will explore how water pressure is affected by its weight and what happens to water pressure when water moves through irrigation pipes.

Water pressure can be measured or expressed in several ways:

- 1) PSI; the most commonly used method in landscape irrigation, pounds of pressure exerted per square inch (PSI),
- feet of head; equivalent to the pressure at the bottom of a column of water 1 ft. high. In this case, the unit of measurement is feet of head (ft./hd).




How pressure is created by the weight of water

What water weighs at 60° F:

- 1 cubic foot (ft.³) or 1728 cubic inches (in.³) of water = 62.37 lb.
- 1 cubic inch, $(in.^3)$ of water = 0.0361 lbs.


Water creates pressure in landscape irrigation systems by the accumulated weight of the water.

In Fig. 1, we can see a container 1 ft. high and 1 ft. wide, holding 1 ft.³ of water, would create a column of water 1 ft. high over every square inch on the bottom of the container.



If we look at just one of those columns, Fig. 2, we can calculate the weight of water pressing on the bottom of the column in pounds per square inch (PSI).

A column 12 in. high resting on a surface at the bottom of 1 in.² represents a column with 12 in.³ of water.



The weight of the 12 in.-high column of water is 0.433 lbs. (12 in.³ x 0.0361 lbs. per in.³ = 0.433 lbs.). Therefore, a column of water 1 ft. high will exert a pressure at the bottom of 0.433 lbs. per in.² or 0.433 PSI. This is a very **important number** because it means that as our column of water gets higher, **every 1 ft. of height added will increase the pressure at the bottom by 0.433 PSI**.

For example, a column of water 2 ft. high creates a pressure at the bottom of 0.866 PSI (0.433 PSI/ft. x 2 ft. = 0.866 PSI).

Important Facts


This gives us some important facts to remember. **Memorize these facts**:

- A column of water 1 ft. high = 1 foot of head = 0.433 PSI.
- 1.0 PSI equals the pressure created by a column of water 2.31 ft. high, or 1 PSI = 2.31 ft. of head (ft./head).
- A column of water 1 ft. high creates 0.433 PSI at the bottom, or 1 ft./head = 0.433 PSI.




Does the shape or size of the container make a difference?


The shape or size of the container does NOT make any difference in the pressure at the bottom, as seen in Fig. 3. Because we are measuring the weight of water in a column resting on 1 in.² regardless of the container's size or shape, pressure at an equal depth will be the same no matter what the shape or size of the container.



While at first this does not seem possible, let's look at two examples that will help us to better understand this concept. First, consider the example of diving into a swimming pool or lake. When you dive below the surface of a lake or pool, the deeper you dive the more pressure builds up on your ears. The amount of increased pressure on your ears does not change with the shape of the pool nor does it change depending on whether you are diving into a backyard pool or a large lake. The pressure at any depth in that pool or lake is dependent upon the **height** of the column of water above that point – not on the shape or size of the pool.



The second example is that of a pipe in a tank of water.



In the diagram, Fig. 4, we can determine the pressure at the bottom of the tank to be 4.33 PSI (0.433 PSI/ft. of depth x 10 ft. water depth). If we lower a 10 ft. long section of irrigation pipe (open on both ends) down into the tank, the pressure at the bottom of the pipe will be the same as that of the surrounding water, 4.33 PSI. What may still be confusing about these concepts is that intuitively we know the TOTAL weight of the water in the pipe and in the larger tank is not the same – and that is true. However, we measure pressure as the force on 1 square inch (pounds per square inch, PSI) not total weight.

What does this mean in irrigation system design?

When designing landscape irrigation systems, for every 1 ft. of elevation change there will be a corresponding change of pressure of 0.433 PSI.



Static and dynamic pressure

There are two classifications of water pressure:


Static and **dynamic**¹ pressure:

- Static pressure is a measurement of water pressure when the water is at rest. In other words, the water is not moving in the system.
- **Dynamic pressure** is a measurement of water pressure with the **water in motion** (also known as working pressure).

Factors affecting static pressure


Static pressure is created either by elevation change or by a pump. Pumps are covered in another training manual so we will concentrate here on the effect of elevation change on static pressure. As previously discussed, each foot of elevation change results in a 0.433 PSI change in pressure. As we can see in the following diagrams, the change in elevation that we are concerned with is the change in **vertical** elevation only, not in the length of pipe. Because water exerts pressure equally in all directions, the **length** of pipe will not affect the **static** pressure (it does affect the dynamic pressure, as we will see later).

If we return to our tank of water, Fig. 5, we can see that inserting a fourteen foot pipe into the tank of water at an angle does not affect the pressure at the bottom of the tank or pipe. **Static** pressure is not affected by the length of the pipe, only by elevation change.




¹ The term "working" pressure may be used instead of dynamic pressure.

We can see the effect of elevation change on static pressure in an irrigation system in Fig. 6 and 7. In the example in Fig. 6, the static pressure at the water meter is 60 PSI. Since the control valve is below the water meter by 8 ft., the static pressure is increased by 3.46 PSI. (8 ft. x 0.433 PSI/ft. = 3.46 PSI).




8 ft. x 0.433 PSI/ft. = 3.46 PSI 60 PSI + 3.46 PSI = 63.46 PSI static pressure

Going uphill **reverses** the process: for every 1 ft. of vertical elevation gain the static pressure will drop by 0.433 PSI.






Static pressure is not affected by the size or length of pipe. Both diagrams in Fig. 8 illustrate a control valve 40 ft. above a water meter. In the first case the main line from the meter to the valve is 100 ft. of two inch pipe and in the second it is 250 ft. of one inch pipe. The **static** pressure at each control valve is 42.68 PSI. Only the **vertical elevation** change affects the static pressure.




Sample problems: determining static pressure

(Answers are on p. 42)

- 1. For every foot of elevation change, the pressure in an irrigation syste m will change by _____ PSI.
- A change in elevation of 231 ft. will cause a change in pressure of ______ PSI.
- 3. 256 ft. of head =_____ PSI





If the static pressure at the water meter discharge (point A) is 75 PSI, the static pressure at point B would be _____ PSI.



Water Movement in Irrigation Systems

When water moves through an irrigation system it is said to be in a dynamic state. The movement of water is described in terms of **velocity** (the speed at which it is moving) and **flow** (the amount of water moving through the system). The velocity is measured in feet per second (FPS) and the flow is measured in gallons per minute (GPM). Dynamic water pressure is measured in the same units as static pressure (PSI).

Factors Affecting Dynamic Pressure

So far we have discussed the factors that affect changes in static pressure. This section will explain factors that affect dynamic pressure. Later, we will discuss the use of pressure loss charts.

Dynamic pressure is affected by the following factors:

- change in elevation (change in elevation affects static and dynamic pressure in the same way)
- 2) friction losses in pipe, valves and fittings (pressure loss is caused by water moving through the system)
- 3) velocity head (the force required to make water move within the system; this is a minor loss and won't be calculated here)
- 4) entrance losses (pressure lost as water flows through openings; this is also a minor loss and won't be calculated here)

Friction loss in pipe


When measuring dynamic pressure at any point in a landscape irrigation system, we must first determine the static pressure at that point and then subtract the pressure losses due to the movement of water.

As water moves through an irrigation system, pressure is lost because of turbulence created by the moving water. This turbulence can be created in pipes, valves, or fittings. These pressure losses are referred to as **"friction losses."**

There are four factors that affect friction losses in pipe:

- 1) the **velocity** of the water,
- 2) the **inside diameter** of the pipe,
- 3) the **roughness** of the inside of the pipe and
- 4) the **length** of the pipe.

1. **VELOCITY** is the speed at which water moves through the system and it is measured in feet per second (FPS). Water moving in the pipe causes turbulence and results in a loss of dynamic pressure. Increasing the velocity will cause increased turbulence and increased pressure losses. In Fig. 9, the inside diameter, roughness, and length remain the same. However, due to increased velocity (FPS), there is a greater dynamic pressure loss. [Note: With the increase in velocity there is a corresponding increase in flow (GPM). Velocity and flow are directly related. An increase or decrease in one will result in a corresponding increase or decrease in the other.]




Effect of velocity on dynamic pressure (See Friction Loss Chart, p. 49, for reference) Fig. 9

When velocity increases, pressure loss increases. When the velocity is increased from 2.97 FPS to 6.67 FPS, the pressure lost in 100 ft. of pipe increases from 1.59 PSI to 7.12 PSI. The velocity typically increases when 1) the flow is increased, such as when additional sprinklers are added to an existing line or 2) a smaller pipe is used with the same flow (GPM).

2. **INSIDE DIAMETER** (i.d.) of the pipe: a smaller inside pipe diameter proportionally increases the amount of water in contact with the pipe surface. This increased contact increases the turbulence and consequently increases the dynamic pressure loss. In Fig. 10, the velocity, length, and roughness remain the same but the inside pipe diameter is reduced. The reduced i.d. results in increased turbulence and reduced dynamic pressure.

(Note: The velocity remains the same even though the pipe size is reduced because there is a corresponding reduction in the flow.)







Even with a smaller flow and the same velocity more turbulence was created in the small pipe because there was a greater percentage of the water in contact with the surface.


3. **ROUGHNESS** of the inside wall of the pipe is the third factor that affects friction loss in pipe. Pipe wall roughness is rated by a "C" factor. The lower the value of C, the rougher the inside wall of the pipe (in standard steel pipe C = 100; in PVC pipe C = 150.) The rougher the inside, the more turbulence created and the greater the pressure loss.

In Fig. 11, the velocity, volume and inside diameter remain the same. As the roughness of the inside of the pipe increases (standard steel has a rougher pipe wall than PVC), there is an increase in turbulence, resulting in a greater pressure loss.





4. LENGTH is the fourth factor affecting friction losses in pipe. The greater the distance, the greater the cumulative effect of the first three factors (velocity, inside diameter, and roughness). In Fig. 12 we see the direct relationship between increased length and increased pressure loss. The total pressure loss doubles as the length of the pipe doubles.



These four factors affecting pressure loss in pipe were used to develop formulas² for calculating the pressure loss associated with various types of pipe. Several formulas were developed; the most common in landscape irrigation hydraulics is the **Hazen-Williams** formula. The Hazen-Williams formula can be represented as:

$$H_{f} = 0.090194 \left(\frac{100}{c}\right)^{1.852} \frac{Q^{1.852}}{d^{4.866}}$$

Where H_f = pressure loss in pounds per square inch (PSI) per 100 ft. of pipe

- C = roughness factor
- Q = flow in gallons per minute (GPM)
- d = inside pipe diameter in inches


Since these formulas are somewhat cumbersome, we will rely on charts developed using the Hazen-Williams formula. Samples of these charts can be found on pages 46-51.


² Crocker, King Piping Handbook, Fifth Ed., McGraw Hill, 1967, pp. 3-179 to 3-181.



Use of Pressure Loss Charts

Figure 13 below represents a portion of one of the pressure loss charts found in the technical manual.





The components of the typical Friction Loss Chart are described below:

- A) Type of pipe represented in the chart.
- B) IPS Iron Pipe Size indicates that the pipe's outside diameter dimensions correspond to that of iron pipe. All IPS PVC pipe of the same nominal size will have the same outside diameter. For example: all ½" PVC irrigation pipe will have an outside diameter of 0.840 in.; thus all ½" slip fittings will fit on the outside of all types of ½" PVC pipe.
- C) (1120, 1220) Represents a designation for the specifications of the plastic pipe.

- D) SDR Standard Dimension Ratio indicates the pipe's wall thickness as a ratio of the outside diameter. Outside diameter of 1" pipe is 1.315 in. If you divide 1.315 by the SDR, 21, it will give you a minimum wall thickness.³ Minimum wall thickness for 1" Class 200 PVC pipe 1.315/21 = 0.063 in. Class-rated pipes (SDR pipes) maintain a uniform maximum operating pressure across all pipe sizes. This is not true of schedule rated pipes such as Schedule 40 PVC. In schedule rated pipes the maximum operating pressure decreases as pipe size increases.
- E) C=150 indicates the value of the C factor, which is a measure of the roughness of the inside of the pipe. The lower the number, the rougher the inside of the pipe and the greater the pressure loss. For PVC, C = 150; Galvanized Pipe C = 100.
- F) Designated pressure losses shown in the chart are per 100 ft. of pipe.
- G) Size indicates the "nominal" pipe size. Nominal means "in name only," and none of the actual pipe dimensions are exactly that size. For example, in the ³/₄" pipe, none of the dimensions are actually ³/₄"
- H) OD outside pipe diameter in inches.
- I) ID inside pipe diameter in inches.
- J) Wall Thick wall thickness in inches.
- K) Flow (GPM) flow rate in gallons per minute.
- L) Velocity (FPS) speed of water in feet per second at the corresponding flow rate.
- M) PSI Loss pressure loss per 100 ft. of pipe in pounds per square inch at the corresponding flow rate.
- N) The shaded area on the chart designates those flow rates that exceed 5 FPS. It is recommended that caution be used with flow rates above 5 FPS in main lines where water hammer will be a concern.

³ There may be exceptions to this rule in the smallest pipe size of each class of pipe, as the minimum wall thickness allowed is 0.060 in. In these cases, either the wall thickness is rounded up to 0.060 in. (1" Class 160 PVC wall thickness is rounded up to 0.060 in.) or that pipe classification is not made in the smaller sizes (Class 200 PVC is not made in $\frac{1}{2}$ " size).



What the charts are used for

These charts are used to:

- Determine the pressure loss in pipe due to friction losses
- Determine the velocity at various flow rates
- Use pressure losses and/or velocities to determine appropriate pipe sizes (pipe sizing is covered in another training manual)

Determining pressure loss in pipes with Friction Loss Charts

Using the Friction Loss Chart for Class 315 PVC on page 48:

- 1) Find the flow of water in gallons per minute (GPM) in the column on the left.
- 2) Read across to the right to the column for PSI loss corresponding to the specific pipe size.
- 3) Divide this number by 100 to find the PSI loss per foot.
- 4) Multiply this number times the length of the pipe in feet.

Example No. 1: Determine the pressure lost in 175 ft. of 1" Class 315 PVC pipe with a flow of 10 gal. per min. (GPM).

- PSI loss per 100 ft. = 1.74 (from the chart)
- 1.74 PSI loss per 100 ft./100 = 0.0174 PSI loss (PSI loss per 100 ft. divided by 100 to find PSI loss per foot)
- 0.0174 PSI loss per foot x 175 ft. = 3.05 PSI
- 3.05 PSI loss in 175 ft. of 1" Class 315 PVC at 10 GPM.

Example No. 2: Determine the maximum flow allowed in a 1" Class 315 PVC pipe without allowing the velocity to exceed 5 ft. per sec. (FPS).

- Find the velocity column for 1" Class 315 PVC and read down the column until you find the velocity closest to (but not exceeding) 5 FPS.
- This should be 4.87 FPS. Now read across to the left hand column to find the flow at that velocity (15 GPM).
- The most water you can put through a 1" Class 315 PVC pipe without exceeding 5 FPS is 15 GPM.

Sample problems: using Friction Loss Charts

(Answers are on p. 42)

Using the chart on page 48 for Friction Loss Characteristics in PVC Class 315 IPS Plastic Pipe, answer the following questions:

- 1) What is the pressure loss in 100 ft. of ½" Class 315 PVC at 6 GPM?
- 2) What is the pressure loss in 100 ft. of ³/₄" Class 315 PVC at 6 GPM?
- 3) What is the pressure loss in 50 ft. of 1" Class 315 PVC at 12 GPM?
- 4) What is the pressure loss in 780 ft. of 1¹/₂" Class 315 PVC at 20 GPM?
- 5) What is the pressure loss in 0.5 ft. of 1" Class 315 PVC at 12 GPM?
- 6) What is the maximum amount of water that can flow through 100 feet of 1" Class 315 PVC pipe and not lose more than 1.0 PSI?
- 7) What is the maximum amount of water that can flow through a ³/₄" Class 315 PVC pipe and not exceed 5 FPS?




Determining Dynamic Pressure Losses in Pipe

When calculating dynamic pressures we use the following factors:

- A) Pressure change due to elevation change.⁴
- B) Pressure loss due to friction losses in the pipe (based on the factors mentioned on p. 12).
- C) Pressure losses in valves, meters, etc. (These losses are determined by the manufacturer and listed in product literature or technical charts.)
- D) Pressure losses due to fittings. (See p. 40 for additional information.)

The following example illustrates how the dynamic pressure at a given point in a landscape irrigation system is determined. Pressure change due to the change in elevation is calculated and the friction losses are subtracted from the sub-total. The example and the following sample problems use the Friction Loss Charts at the back of the manual.



In Fig. 14, all the pipe is 1¹/₄" Class 200 PVC and the flow is 18 GPM from point A to point B. At point A a pressure gauge reading indicates 85 PSI. In order to determine the dynamic pressure at point B, first find the pressure change due to change in elevation and then combine that with the friction loss in the pipe.

⁴ Elevation change affects both static and dynamic pressure in the same way.

Pressure loss due to the higher elevation at point B (an elevation gain):

75 ft. x 0.433 PSI per ft. of elevation change = 32.48 PSI less at point B

Pressure loss due to friction in the pipe:

Use the friction loss charts at the back of the manual to find the pressure loss at 18 GPM in 1¹/₄" Class 200 PVC pipe: friction loss from the chart is 1.24 PSI per 100 ft.

PSI loss in pipe:

(50 ft. + 100 ft. + 100 ft.) x (1.24 PSI loss per 100 ft. ÷ 100 ft.) = PSI loss

Note: the 1.24 PSI loss from the charts is PSI loss per 100 ft. and is divided by 100 to find the pressure loss per foot, $(1.24 \div 100 = 0.0124)$.

PSI loss in pipe = 250 ft. x 0.0124 PSI loss per ft.


PSI loss in pipe = 3.10 PSI [total due to friction loss]

85.00	PSI pressure at point A
-32.48	PSI due to elevation change
52.52	PSI subtotal at point B
- 3.10	PSI due to friction loss in pipe from point A to point B
49.42	PSI dynamic pressure at point B


Sample problems: dynamic pressure

(Answers are on p. 43)

 In the diagram below, if the dynamic pressure at point A is 70 PSI, what would the dynamic pressure be at point B (no elevation change)?







General Principles of Water Flow in an Irrigation System

Water in an irrigation system has energy called pressure. The pressure may be created by the weight of a column of water, as discussed in the section on Static Pressure, or the pressure may be created by a pump. In the following section, you will see that as water flows through an irrigation system all of the energy or pressure that is available at the source is expended. Some of the pressure is expended as friction losses in pipes, valves, and fittings and some is used to create velocity and flow. The flow and velocity will increase until all the pressure available at the source is consumed as friction losses or used to create velocity. For example, an irrigation system with 50 PSI at the source will expend **all** 50 PSI between the source and the point where the water has left the system (an open pipe or sprinkler nozzle). **The quantity** (**GPM**) **and velocity (FPS) will increase until the cumulative pressure losses, from the source to the outlet, equal the pressure available at the source.**


In other words, every pound of increased pressure at the water source will cause more water to flow through the outlet. As the flow increases so does the velocity resulting in increased pressure losses. These increased pressure losses will equal the increase in pressure at the source.

Factors Affecting Flow in an Irrigation System

The flow in an irrigation system is determined by three factors:

- 1) the pressure (PSI) available at the source (p. 24)
- 2) the **pressure losses from the source to the outlet(s)**, (p. 25 & 26) and
- 3) the size and number of outlets (p. 29)


In our examples we start with a tank filled with water. It is 115.5 ft. from the water surface to the tank outlet. The water pressure created at the tank outlet is 50 PSI ($0.433 \times 115.5 = 50$).





How the pressure available at the source affects flow

The 50 PSI at the tank outlet, shown in Fig. 16, is created by a water tank full to 115.5 ft. above the tank outlet (115.5 ft. x 0.433 PSI per ft. = 50 PSI). In the first example, we have opened a fill-line and used a float valve to maintain a constant water level allowing water from the fill-line to replace water leaving through the tank outlet.




he effect of adding pipe to the syster Fig. 16

With the 2" Class 315 PVC discharge line wide open (unrestricted flow), the water velocity (FPS) increases until all of the available pressure is lost to friction in the pipe, fittings, or other losses. The increased velocity creates increased pressure losses until the pressure losses equal the pressure available at the source. Under these conditions the velocity is 26 FPS and the flow is 260 GPM. This is greater than the velocities and pressure losses listed in friction loss charts. Mathematical formulae were used to calculate the velocity and flow. (Illustrated on page 26)

Now where did that pressure go? One of the most difficult concepts to understand is how water that has left a pipe, like the one in the diagram above, no longer has any pressure. Remember, the water velocity in the pipe will increase until all the pressure available at the source is consumed. Consider the water leaving the "fill line" at the top of the tank. As this water leaves the pipe and flows into the top of the tank, it is no longer under pressure.

Another example is water from a hose that flows out onto the ground. The water velocity in the hose increases until all the pressure available at the source has been consumed. When the water flows out onto the ground, it is no longer under pressure.

No one should design an irrigation system with the velocity and flow this high; therefore, 26 FPS and 260 GPM are not even listed on the normal pressure loss/velocity charts and were calculated by formula instead. As we will see later, the flow and velocity are kept to much lower levels by regulating the number of sprinklers on a pipe or valve, which, in turn, regulates the flow. Next we look at what happens when the water pressure at the source drops. In Fig. 17, the fill-line has been shut off and the water level in the tank allowed to drop. When the level in the tank has dropped to a depth of 46.19 ft. above the tank outlet the pressure at the outlet is 20 PSI (46.19 x 0.433 = 20 PSI). As might be imagined, the flow through the pipe outlet has been reduced. With the pressure at 20 PSI, the discharge is approximately 160 GPM at a velocity of 16 FPS. **The drop in flow resulted from the drop in pressure at the source.**



. Fig. 17

A pressurized irrigation system will dissipate all the pressure at the source by the time the water leaves the discharge point. As shown in Figs. 16 and 17, the water velocity and flow increase in the pipe until the total pressure losses incurred, from the tank to the pipe outlet, equal the pressure available at the source.

Pressure at the source directly affects the velocity and flow in an irrigation system. At 20 PSI at the source, the velocity is 16 FPS and the flow is 160 GPM. If the tank is filled back to 115.5 ft., the flow increases until there is a total of 50 PSI in pressure losses from the source to the discharge (260 GPM at 26 FPS).

How pressure losses from the source to the outlet affect flow.

In Fig. 18, there is a constant pressure at the source of 50 PSI and an unrestricted flow through 100 ft. of 2" Class 315 PVC pipe. Under these conditions, the amount of water that will flow through the pipe is approximately 260 GPM at 26 FPS.

With 50 PSI at the source, the flow of water through the pipe increases until it reaches 26 FPS. At 26 FPS pressure losses from the inlet of the pipe to the outlet equal the pressure available at the source. Fig. 18, and the table below show how and where the 50 PSI at the source is lost.






Fig. 18

Friction loss in pipe – At 26 FPS through a 2" Class 315 PVC pipe (this is above the velocities and pressure losses listed in the pressure loss charts and was computed using the mathematical formulæ for pressure losses in pipe): Approximately **41.0 PSI** loss

Friction loss in fittings – Pressure lost in the four couplings (PVC pipe is made in 20-ft. sections requiring four couplings to assemble 100 ft. of pipe): Approximately **1.5 PSI** loss

Velocity head – This is the pressure required to generate 26 FPS (amount of pressure required to move the water through the pipe at 26 FPS):.....Approximately **4.5** PSI loss

Total pressure lost or consumed: 50 PSI

Note:

- Friction loss calculations made with the Hazen-Williams formula (see p. 15).
- Friction loss in couplings estimated to be 0.9 equivalent foot each.
- Velocity head calculated as equal to $\left(\frac{V^2}{2g}\right)$ 0.433 (calculated per Irrigation, Fifth Ed., p. 240).
- Entrance losses calculated as equal to $0.5 \left(\frac{V^2}{2g}\right) 0.433$ (calculated as a function of velocity as per Irrigation, Fifth Ed., p. 241).
- Where V = Velocity in ft./sec.; g = Acceleration due to gravity (32.2 ft./sec.).

If there is an increase in pressure (PSI) at the source, the rate of flow (GPM) and velocity (FPS) will also increase. When the flow and velocity are increased, the pressure losses from friction, velocity head and entrance losses also increase. The rate of flow increases until all the additional pressure is used to create a higher flow (GPM) and velocity (FPS). In our examples, the flow at 20 PSI is approximately 160 GPM. If the pressure is increased by 30 PSI, from 20 to 50 PSI at the source, the flow will increase by 100 GPM from approximately 160 GPM to 260 GPM. The increase of 100 GPM in the flow will increase pressure losses by 30 PSI, so that by the time the water has left the pipe, all the pressure available at the source will have been used.

Some Practical Examples:

A) **The laminar flow drip emitter:** If the pipe is small enough and long enough, the pressure loss will be so great that the water will just drip out. This is how some drip emitters work. Long, small water pathways (like pipes) inside the emitters cause so much pressure loss that very little velocity or flow remain at the discharge point.

B) **Nozzle size controls flow:** In a sprinkler system, the water flow is less than that from an open-ended pipe. Flow is controlled by limiting the number of sprinklers per control valve and the size of the sprinkler nozzles. The nozzles are smaller than the open pipe. The smaller nozzles control the flow of water in the system. Because of the reduced flow and velocity there is reduced pressure loss from the water source to the sprinkler head. The pressure available at the sprinkler is expended as the water escapes through the small nozzle. At the nozzle, the water velocity increases as it exits at the nozzle, and this increased velocity dissipates the remaining pressure. This increased velocity throws the water up to a hundred feet or more, depending on the sprinkler design.


C) **The "thumb on the hose" trick:** Turn on a long hose and the water barely comes out. If you put your thumb over the end of the hose and allow just a tiny amount of water to flow past your thumb, you have reduced the velocity and flow through the hose, which results in less pressure loss. The pressure you have conserved is now converted to a higher velocity as the water flows past your thumb. The higher velocity will cause the water to be thrown farther than before. This sometimes leaves a person with the impression that a smaller pipe increases pressure. In reality, the reduced flow results in more pressure remaining at the end of the hose, which in turn creates more velocity as the water leaves the hose.



The relationship between pressure and flow.

Figure 19, charts the relationship between pressure at the source and flow. This relationship is shown for three sizes of PVC pipe. There are three points that should be noted about this chart.

- 1) **Increasing pressure at the source increases the flow.** On the chart the two bold dashed lines indicate the increase in flow from 160 GPM to 260 GPM as the pressure at the source is increased from 20 PSI to 50 PSI.
- 2) Using smaller pipe does not increase the flow. Smaller pipe sizes have less flow at any given pressure. Since decreasing pipe size does not increase the pressure at the source, the result of decreasing pipe size is a reduced flow (GPM).
- 3) Using smaller pipe does not result in higher pressure. Smaller pipe leads to greater pressure loss. For example, on the chart, a flow of 20 GPM in our 1" pipe would require a pressure at the source of about 9 PSI. In order to maintain the same 20 GPM flow in the smaller ½" pipe, we would need over 50 PSI at the source. Smaller pipe results in greater pressure loss, not higher pressure.




* Approximate flow through an unrestricted 100-ft.-long section of pipe with four couplings. Pressure losses include: friction loss in pipe and couplings, velocity head and entrance losses. Exit losses not included.

The relationship of pressure and flow* Fig. 19


How the size of the outlet affects flow.

At first it would seem that any 100-ft.-long section of 2" class 315 PVC pipe with 50 PSI at the source should have a flow of 260 GPM. However, it must be remembered that the size of the outlet at the discharge end of the pipe will also affect the flow of water.



How flow is affected by a closed gate valve Fig. 20

Fig. 20 is the most extreme example of this principle; the pipe has a closed gate valve that completely stops the flow. Even though the pipe is still the same size and has the same pressure at the source, there is NO flow.



How flow is affected by a PGP[®] sprinkler Fig. 21

In Fig. 21, we have replaced the gate valve with a Hunter PGP[®] sprinkler with a #5 Nozzle. Because the outlet is so much smaller than the pipe,with 50 PSI at the source, it will allow a flow of only 2.0 GPM⁵.

⁵ Pressure loss in 100 ft. of 2" Class 315 PVC at 2.0 GPM is less than 0.1 PSI; therefore performance of the PGP[®] sprinkler is based on 50 PSI.



Note: The diagram indicates 0 PSI at the outlet of the nozzle, yet if we place a pressure gauge, with a Pitot tube⁶, into the stream of water leaving the sprinkler nozzle, it will indicate water pressure. This is because the energy (pressure) remaining when the water reaches the sprinkler is converted to velocity. The pressure remaining when the water reaches the sprinkler is still nearly 50 PSI and the nozzle outlet is small. This pressure at the sprinkler is used to create a high velocity as the water flows through the nozzle. When the water is stopped by the pressure gauge, the velocity is converted back to pressure. When the sprinkler is operating, the energy contained in the water's high velocity is dissipated as the water pushes through the air. As the velocity is reduced the water falls to the ground.


As shown in the previous examples, the flow in an irrigation system is controlled by:

- 1) The pressure (PSI) available at the source. Increasing the pressure at the source increases the flow in the system; more pressure is available to compensate for the increased pressure losses in the system.
- 2) The pressure losses from the source to the outlet(s). Reducing pipe size or any other factor which causes a greater pressure loss will result in reduced flow.
- 3) The size or number of the outlet(s). Changing the size or number of outlets, such as changing the size of the sprinkler nozzles or the number of sprinklers on a line, will change the amount of flow.


⁶ A Pitot tube is a device that consists of a tube having a short right-angled bend which is placed into a stream of water with the mouth of the bent part directed upstream and is used with a pressure gauge.

What Happens When the Water Reaches a Sprinkler Head?

It is important to see how hydraulic principles apply to a landscape irrigation system. To better understand how a typical system works, let's look at a sprinkler system that has four sprinklers using 10 GPM each for a total of 40 GPM. The system has 30 PSI at the control valve and has been installed as shown in Fig. 22.



When the system is in operation, 10 GPM flows from each sprinkler head. The pressure at each sprinkler remains relatively constant because the pipe and fittings have been sized to minimize pressure loss. For the sake of this example we will assume a negligible pressure loss so that each sprinkler is operating at 30 PSI. Later we will examine the pressure losses between each head.




Pressure at sprinkler heads when system is operating Fig. 23

At point A (below sprinkler No. 1) in Fig. 23, the flow of water splits, with 10 GPM flowing up and out of sprinkler No. 1 and 30 GPM flowing on to sprinkler No. 2. The pressure, however, does not split. Instead, the pressure is equal in both directions at point A. At point B



the flow of water splits in the same way it did at point A with 10 GPM flowing to the sprinkler and 20 GPM flowing toward sprinklers farther down the line. Once again, the pressure does not split. The pressure at point B (below sprinkler No. 2) is 30 PSI both at the base of the sprinkler as well as in the direction of the sprinklers downstream.

Because this is a difficult concept to understand, Fig. 24 shows a variation on the same principle.



Pressure at sprinkler heads in different system layout Fig. 24


In this example, 30 GPM enters the horizontal pipe at point A at 30 PSI. Ten gallons per minute then flow to sprinkler No. 1 and 20 GPM flow toward sprinklers No. 2 and No. 3. The pressure, however, at point A is pushing the water equally in both directions with 30 PSI. The volume splits but the pressure pushes equally in both directions.

The same situation occurs at point B where the water pressure is 30 PSI pushing toward sprinkler No. 2 and 30 PSI pushing toward sprinkler No. 3. In this case the 20 GPM splits, with 10 GPM going to sprinkler No. 2 and 10 GPM going on to sprinkler No. 3. The flow of water splits at each of these points but the pressure is pushing equally in each direction.

Flow and Pressure Loss in a Typical Sprinkler System

In the previous section we assumed each sprinkler was operating at exactly the same pressure. In reality there are some pressure losses in the pipe between each head. In this section we will see how to calculate those pressure losses that occur between sprinklers to determine if our system will operate properly.


Fig. 25 illustrates a system with four sprinklers controlled by one valve. While there is some loss of pressure between the sprinklers, we will still assume they are delivering 6.0 GPM.



Flow and pressure loss in an irrigation system Fig. 25

In order to keep pressure losses to a minimum and thereby maintain a relatively uniform pressure throughout the system, the lateral line pipe has been sized as shown in Fig. 26. (Pipe sizing is covered in another education module, but for clarification, pipe is downsized when volume is reduced because smaller pipe and fittings are less expensive.)





As water flows through our sprinkler system, the pressure losses due to friction and the other factors **reduce the pressure available at the sprinklers**. Each sprinkler on the line has less pressure than the one before it (assuming the system is not running down a slope). It is important to maintain relatively uniform pressures for all sprinklers on a given control valve because sprinkler performance (GPM and radius of throw) will vary as the pressure at each sprinkler varies. Our design goal is to have all sprinklers controlled by one valve within +/- 10% of the pressure at which they were designed to operate.

In our sample problem, according to the sprinkler manufacturer's specifications, the sprinklers have been designed to operate at 60 PSI. This means that +/-10% of the designed operating pressure is an operating range of 54 – 66 PSI. Since we have 60 PSI at the discharge of the valve, we must check to be sure that we have at least 54 PSI (a 10% variation) at the last head (Note: If the pipe were running down a slope, you would want to be sure you did not have more than 66 PSI). We can check to see if we have sufficient pressure at the last sprinkler by determining the pressure loss through each section of pipe. The following table, Fig. 27, will aid in these calculations.

(Note: Even though we know there is a slight drop in pressure at each succeeding sprinkler, resulting in a slightly lower GPM, for the sake of simplifying the calculations we will still use 6 GPM for the flow from each sprinkler.)

Pipe <u>Section</u>	Type	<u>Size</u>	<u>GPM</u>	<u>Length</u>	PSI loss/ <u>100 ft.</u> ²	Actual <u>PSI Loss⁸</u>				
А	Cl. 200	3⁄4 "	6	46 ft.	1.67	0.77				
В	Cl. 200	1"	12	46 ft.	1.83	0.84				
С	Cl. 200	1¼"	18	46 ft.	1.24	0.57				
D	Cl. 200	1¼"	24	46 ft.	2.12	0.98				
C Cl. 200 1 ¹ / ₄ " 18 46 ft. 1.24 0.57										

Pressure at the valve discharge	60.00 PSI
Pressure loss in pipe from valve to last head	-3.16 PSI
Estimated pressure loss in fittings (10% of pipe loss) ⁹	-0.32 PSI
Pressure remaining at the last head	56.52 PSI

Pressure loss calculations Fig. 27

The preceding example illustrates the pressure losses in pipe. By performing this calculation we can check to see if we have designed our system to maintain a sprinkler pressure at each head within 10% of the pressure at which the head was designed to operate. This is important because it assures us the system will operate properly before it is installed. This type of calculation would not have to be performed for every valve on a project, just for the valve most likely to have the lowest pressure (the "worst-case" scenario).


The following are sample problems for pressure loss calculations.

⁷ Refer to the class 200 PVC Friction Loss chart on pg. 47.


⁸ Refer to p. 20 for more information on calculating actual pressure loss in pipe.


⁹ Refer to p. 40 for more information on pressure loss in fittings.






2) Determine the dynamic pressure at the "worst-case sprinkler" in the diagram by filling in the table below. (Use the Pressure Loss Charts at the back of this manual.)





- Pressure loss in pipe from valve to last head _____ PSI
- Estimated pressure loss in fittings (10% of pipe loss) _____ PSI
 - Pressure remaining at the last head _____ PSI

4) Determine the dynamic pressure at the "worst-case sprinkler" in the diagram by filling in the table below. In this example the lateral line pipe used is polyethylene (PE or Poly pipe). (Use the Pressure Loss Chart at the back of this manual)



Pressure remaining at the last head _____ PSI



Pressure Loss in Fittings

While more accurate pressure losses can be determined, irrigation designers often estimate the pressure loss in fittings as a percentage of the pressure lost in the pipe. For example, if a section of pipe from the control valve to the worst case sprinkler had a friction loss of 4.0 PSI the pressure loss in the fittings would be estimated at 10 - 20% of the pressure loss in the pipe, depending on the system design. In our examples an estimate of 10% is deemed reasonable. Pressure losses of 25% or more may occur in systems with a large number of 90° elbows and/or heads spaced closer together, as might be the case in irregular-shaped planters around apartments or condos.

Summary

The design of a landscape irrigation system requires an understanding of hydraulics. Changes in elevation and friction losses in pipe, valves and fittings affect pressure, which in turn affects sprinkler performance. Irrigation hydraulics is used to determine the volume of water available for use by the system, the pressure available at the sprinkler heads, and the correct pipe sizes. Irrigation designers who understand hydraulics can design systems that are more efficient and cost less.

Important Definitions

- 1) Static Pressure The pressure of water at rest. *unit of measure = pounds per square inch (PSI)* Static pressure is affected by elevation change or by the force of a pump. For each 1 ft. of elevation change, static pressure (or dynamic pressure) changes by 0.433 PSI.
- 2) **Dynamic Pressure** The pressure of water in motion. Dynamic pressure is affected by changes in pressure caused by either elevation change or a pump, as well as by friction losses in pipe, valves, and fittings.

unit of measure = pounds per square inch (PSI)

- 3) Velocity The speed at which water is moving. *unit of measure = feet per second (FPS)*
- 4) **Flow** The quantity of water moving through the system. Flow is affected by: (a) the pressure available at the source, (b) the pressure losses from the source to the outlet or outlets, and (c) the size or number of outlet(s).

unit of measure = gallons per minute (GPM)

5) Friction Loss – A term used to identify pressure losses caused by water turbulence. Friction loss is affected by: (a) velocity, (b) pipe inside diameter, (c) roughness of the inside of the pipe, and (d) length of the pipe.

unit of measure = pounds per square inch per 100 ft. of pipe (PSI/100 ft.)

6) Velocity Head – The amount of pressure required to generate a specific velocity. This is the amount of energy or pressure that is used to make the water move at a given velocity.

unit of measure = PSI or feet of head (ft./head)



Static Pressure - p. 10

- 1) 0.433 PSI
- 2) 231 ft. x 0.433 PSI per ft. = 100.02 PSI
- 3) One foot of head is equal to the pressure created by a column of water 1 ft. high.
 256 ft. v. 0.422 PSL per ft. 110.85 PSL

256 ft. x 0.433 PSI per ft. = 110.85 PSI

4) A) 43.3 PSI

B) 43.3 PSI The pressure is the same in both pipes because it is determined by the height of the column of water above that point regardless of the diameter of the pipe.

5) 103.15 PSI

Since we are measuring static pressure, the length of pipe does not affect the pressure loss; the only factor is the elevation change which is multiplied by 0.433 PSI per ft.

- 125 ft. 60 ft. = 65 ft. elevation change to point B downhill
- 65 ft. x 0.433 PSI = 28.15 PSI increase
- 75 PSI + 28.15 PSI = 103.15 PSI

Using Friction Loss Charts - p. 19

- 1) 5.97 PSI
- 2) 2.03 PSI
- 3) 1.22 PSI
- 4) 8.19 PSI
- 5) 0.01 PSI
- 6) 7 GPM
- 7) 9 GPM

Dynamic Pressure Losses in Pipe - p. 21

yna	IIIIC FIESS	ure Losses in Fipe - p. 21
1)	PSI loss in	pipe = 7.32 PSI loss per 100 ft. x 325 ft. pipe = 0.0732 per ft. x 325 ft. pipe = 23.79 PSI
		PSI pressure at point A
	46.21	PSI dynamic pressure at point B
2)		e to elevation gain = 0.433 PSI per ft. x 50 ft. e to elevation gain = 21.65 PSI
	PSI loss in	pipe = 3.11 PSI loss per 100 ft. x 125 ft. per 100 pipe = 0.0311 per ft. x 125 ft. pipe = 3.89 PSI
	85.00 - 21.65	1 1
	63.35 - 3.89	1
	59.46	PSI dynamic pressure at point B
3)	PSI gain du (80 ft 40 f	e to elevation change = 0.433 PSI per ft. x (ft.)
	PSI gain du	e to elevation change = 0.433 PSI per ft. x 40 ft.
	-	e to elevation change = 17.32 PSI pipe = 2.43 PSI loss per 100 ft. x (99 ft. + 45 ft. + ft.)
	-	pipe = 0.0243 per ft. x 245 ft. pipe = 5.95 PSI
	45.00 +17.32	PSI pressure at point A PSI due to elevation change
	62.32	PSI subtotal at point B
	- 5.95	PSI due to friction loss in pipe
	56.37	PSI dynamic pressure at point B



Dynamic Pressure Losses in Irrigation Systems - pg. 36 1)

Pipe <u>Section</u>	Type	<u>Size</u>	<u>GPM</u>	<u>Length</u>	PSI loss/ <u>100 ft.</u>	Actual <u>PSI Loss</u>			
А	CL. 315	1⁄2"	4	16 ft.	2.82	0.45			
В	CL. 200	3⁄4 "	3⁄4" 8 16 1		2.85	0.46			
С	CL. 200	1"	12	16 ft.	1.83	0.29			
D	CL. 200	1 12 1" 16		16 ft.	3.11	0.50			
Total PSI loss in pipe from the valve to the last head1.70									

Pressure at the valve discharge	35.00 PSI
Pressure loss in pipe from valve to last head	-1.70 PSI
Estimated pressure loss in fittings (10% of pipe loss)	-0.17 PSI
Pressure remaining at the last head	33.13PSI

2)

Pipe <u>Section</u>	<u>Type</u>	<u>Size</u>	<u>GPM</u>	<u>Length</u>	PSI loss/ <u>100 ft.</u>	
А	CL. 200	3⁄4 "	6	45 ft.	1.67	0.75
В	CL. 200	1"	12	45 ft.	1.83	0.82
С	CL. 200	1¼"	18	21 ft.	1.24	0.26
D	CL. 200	2"	36	12 ft.	0.78	0.09

Total PSI loss in pipe from the valve to the last head	1.92 PSI
Pressure at the valve discharge	60.00 PSI
Pressure loss in pipe from valve to last head	-1.92 PSI
Estimated pressure loss in fittings (10% of pipe loss)	-0.19 PSI
Pressure remaining at last head	57.89 PSI

Pipe <u>Section</u>	Type	Size	<u>GPM</u>	Length	PSI loss/ <u>100 ft.</u>	Actual <u>PSI Loss</u>
А	CL. 200	3⁄4 "	6.0	46 ft.	1.67	0.77
В	CL. 200	1"	12.0	23 ft.	1.83	0.42
С	CL. 200	1¼"	18.0	23 ft.	1.24	0.29
D	CL. 200	1¼"	24.0	23 ft.	2.12	0.49
E	CL. 200	1¼"	30.0	23 ft.	3.20	0.74
F	CL. 200	11⁄2"	36.0	46 ft.	2.32	1.07

Total PSI loss in pipe from the valve to the last head	3.78 PSI
Pressure at the valve discharge	60.00 PSI
Pressure loss in pipe from valve to last head	-3.78 PSI
Estimated pressure loss in fittings (10% of pipe loss)	-0.38 PSI
Pressure remaining at last head	55.84 PSI

4)

3)

Pipe <u>Section</u>	Type	<u>Size</u>	<u>GPM</u>	<u>Length</u>	PSI loss/ <u>100 ft.</u>	Actual <u>PSI Loss</u>
А	SDR-PE	1⁄2 "	2.0	38 ft.	1.76	0.67
В	SDR-PE	3⁄4 "	4.0	38 ft.	1.62	0.62
С	SDR-PE	3⁄4 "	6.0	38 ft.	3.43	1.30
D	SDR-PE	1"	10.0	38 ft.	2.73	1.04

Total PSI loss in pipe from the valve to the last head	3.63 PSI
Pressure at the valve discharge	50.00 PSI
Pressure loss in pipe from valve to last head	-3.63 PSI
Estimated pressure loss in fittings (10% of pipe loss)	-0.36 PSI
Pressure remaining at last head	46.01 PSI



					Cla		60 IF	PS P	Charac VC F =150 S	Plas	^{cs} tic P	ipe					
Nominal					PS	SI Loss	Per 100	Feet o	f Pipe	Sizes	1" thru 5	"					Nominal
Size	1"		11	4"	11		2	n	21/	2"	3'	•	4	II.	5		Size
Pipe ID	1.19		1.5		1.7		2.1		2.6		3.2		4.1		5.1		Pipe ID
Pipe OD Wall Thick	1.31		1.60 0.00		1.9 0.0		2.3 0.0		2.8 0.1		3.5 0.1		4.5 0.1		5.5		Pipe OD Wall Thick
		-															0
Flow	Velocity	PSI	Velocity	PSI	Velocity	PSI	Velocity	PSI	Velocity	PSI	Velocity	PSI	Velocity	PSI	Velocity	PSI	Flow
GPM 1	FPS 0.29	LOSS 0.02	FPS 0.17	LOSS 0.01	FPS 0.13	LOSS 0.00	FPS	LOSS	FPS	LOSS	FPS	LOSS	FPS	LOSS	FPS	LOSS	GPM 1
2	0.57	0.06	0.35	0.02	0.27	0.01	0.17	0.00									2
3	0.86	0.14	0.52	0.04	0.40	0.02	0.25	0.01									3
4 5	1.14 1.43	0.23 0.35	0.70 0.87	0.07 0.11	0.53 0.66	0.04 0.05	0.34 0.42	0.01 0.02	0.23	0.00 0.01							4 5
6	1.43	0.33	1.04	0.15	0.80	0.03	0.42	0.02	0.25	0.01	0.23	0.00					6
7	2.00	0.66	1.22	0.20	0.93	0.10	0.59	0.03	0.41	0.01	0.27	0.01					7
8 9	2.29	0.84	1.39	0.25	1.06	0.13	0.68	0.04	0.46	0.02	0.31	0.01					8
9 10	2.57 2.86	1.05 1.27	1.56 1.74	0.31 0.38	1.19 1.33	0.16 0.20	0.76 0.85	0.05 0.07	0.52 0.58	0.02 0.03	0.35	0.01 0.01					9 10
11	3.14	1.52	1.91	0.45	1.46	0.23	0.93	0.08	0.64	0.03	0.43	0.01					11
12	3.43	1.78	2.09	0.53	1.59	0.28	1.02	0.09	0.69	0.04	0.47	0.01					12
13 14	3.71 4.00	2.07 2.37	2.26 2.43	0.62 0.71	1.72 1.86	0.32 0.37	1.10 1.19	0.11 0.12	0.75 0.81	0.04 0.05	0.51 0.55	0.02 0.02	0.31 0.33	0.00 0.01			13 14
14	4.00	2.70	2.43	0.80	1.99	0.42	1.13	0.12	0.87	0.05	0.59	0.02	0.35	0.01			14
16	4.57	3.04	2.78	0.91	2.12	0.47	1.36	0.16	0.93	0.06	0.63	0.02	0.38	0.01			16
17	4.86	3.40	2.96	1.01	2.25	0.53	1.44	0.18	0.98	0.07	0.66	0.03	0.40	0.01			17
18 19	5.14 5.43	3.78 4.18	3.13 3.30	1.13 1.25	2.39 2.52	0.58 0.65	1.53 1.61	0.20 0.22	1.04 1.10	0.08 0.09	0.70	0.03 0.03	0.43 0.45	0.01 0.01			18 19
20	5.71	4.59	3.48	1.37	2.65	0.71	1.70	0.24	1.16	0.09	0.78	0.04	0.47	0.01			20
22	6.29	5.48	3.82	1.64	2.92	0.85	1.87	0.29	1.27	0.11	0.86	0.04	0.52	0.01	0.34	0.00	22
24 25	6.86 7.14	6.44 6.94	4.17 4.35	1.92 2.07	3.18 3.32	0.99 1.07	2.04 2.12	0.34 0.36	1.39 1.45	0.13 0.14	0.94 0.98	0.05 0.05	0.57 0.59	0.01	0.37	0.01 0.01	24 25
25	7.14	7.47	4.55	2.07	3.45	1.15	2.12	0.30	1.45	0.14	1.02	0.05	0.59	0.02		0.01	25
28	8.00	8.56	4.87	2.56	3.71	1.32	2.38	0.45	1.62	0.18	1.09	0.07	0.66	0.02	0.43	0.01	28
30	8.57	9.73	5.22	2.91	3.98	1.50	2.55	0.51	1.74	0.20	1.17	0.08	0.71	0.02	1	0.01	30
32 34	9.14 9.71	10.97 12.27	5.56 5.91	3.27 3.66	4.24 4.51	1.69 1.90	2.71 2.88	0.57 0.64	1.85 1.97	0.23 0.25	1.25 1.33	0.09 0.10	0.76 0.80	0.03 0.03	1	0.01 0.01	32 34
35	10.00	12.95	6.08	3.87	4.64	2.00	2.97	0.67	2.03	0.27	1.37	0.10	0.83	0.03	1	0.01	35
36	10.29	13.64	6.26	4.07	4.77	2.11	3.05	0.71	2.08	0.28	1.41	0.11	0.85	0.03	0.56	0.01	36
38 40	10.86 11.43	15.08 16.58	6.61 6.95	4.50 4.95	5.04 5.30	2.33 2.56	3.22 3.39	0.79 0.86	2.20 2.32	0.31 0.34	1.49 1.56	0.12 0.13	0.90 0.95	0.04 0.04	0.59	0.01 0.01	38 40
40	12.00	18.15	7.30	5.42	5.57	2.80	3.56	0.95	2.43	0.34	1.64	0.13	0.99	0.04	1	0.02	40
44	12.57	19.78	7.65	5.91	5.84	3.06	3.73	1.03	2.55	0.41	1.72	0.16	1.04	0.05	0.68	0.02	44
45	12.86	20.62	7.82	6.16	5.97	3.19	3.82	1.07	2.60	0.42	1.76	0.16	1.06	0.05	0.70	0.02	45
46 48	13.14 13.71	21.48 23.24	8.00 8.34	6.41 6.94	6.10 6.37	3.32 3.59	3.90 4.07	1.12 1.21	2.66 2.78	0.44 0.48	1.80 1.88	0.17 0.18	1.09 1.13	0.05 0.05	0.71	0.02 0.02	46 48
50	14.29	25.07	8.69	7.48	6.63	3.87	4.24	1.31	2.89	0.52	1.96	0.20	1.18	0.06	1	0.02	50
55	15.71	29.90	9.56	8.93	7.29	4.62	4.67	1.56	3.18	0.61	2.15	0.24	1.30	0.07	0.85	0.02	55
60 65	17.14 18.57	35.13 40.75	10.43 11.30	10.49	7.96	<u>5.43</u> 6.30	5.09 5.51	1.83	3.47 3.76	0.72	2.35	0.28	1.42 1.54	0.08	0.93	0.03	60 65
70	10.07	40.75	12.17	13.95	9.28	7.22	5.94	2.44	4.05	0.96	2.74	0.37	1.66	0.11		0.04	70
75			13.04	15.86	9.95	8.21	6.36	2.77	4.34	1.09	2.93	0.42	1.77	0.12	1	0.04	75
80 85			13.91	17.87 19.99	10.61	9.25 10.35	6.79	3.12 3.49	4.63 4.92	1.23 1.38	3.13	0.47 0.53	1.89	0.14 0.16	1	0.05 0.06	80
90			14.78 15.65	22.23	11.27 11.94	11.50	7.21 7.64	3.88	5.21	1.50	3.32 3.52	0.53	2.01 2.13	0.10		0.06	85 90
95			16.51	24.57	12.60	12.72	8.06	4.29	5.50	1.69	3.72	0.65	2.25	0.19	1.47	0.07	95
100 110			17.38 19.12	27.01 32.23	13.26 14.59	13.98 16.68	8.48 9.33	4.72 5.63	5.79 6.37	1.86 2.22	3.91 4.30	0.72	2.36	0.21 0.25	1	0.08 0.09	100
120			19.12	32.23	14.59	19.60	9.33	5.63 6.61	6.95	2.22	4.30	0.85 1.00	2.60 2.84	0.25		0.09	110 120
130					17.24	22.73	11.03	7.67	7.52	3.02	5.08	1.16	3.07	0.34	2.01	0.12	130
140					18.57	26.08	11.88	8.79	8.10	3.47	5.47	1.34	3.31	0.39	1	0.14	
150 160					19.89	29.63	12.73 13.57	9.99 11.26	8.68 9.26	3.94 4.44	5.87 6.26	1.52 1.71	3.55 3.78	0.45 0.50	1	0.16 0.18	
170							14.42	12.60	9.84	4.97	6.65	1.91	4.02	0.56	1	0.20	170
180							15.27	14.01	10.42	5.52	7.04	2.13	4.26	0.63	1	0.22	
190 200							16.12 16.97	15.48 17.02	11.00 11.58	6.11 6.72	7.43 7.82	2.35 2.59	4.49 4.73	0.69 0.76		0.25 0.27	190 200
200							19.09	21.17	13.02	8.35	8.80	3.22	5.32	0.95	-	0.27	
250									14.47	10.15	9.78	3.91	5.91	1.15	3.87	0.41	250
275									15.92	12.11	10.75	4.67	6.50	1.37		0.49	275
300 325									17.36 18.81	14.23 16.50	11.73 12.71	5.48 6.36	7.09 7.68	1.61 1.87	4.65	0.58	300 325
350									. 5.61		13.69	7.29	8.28	2.14	1	0.77	350
375											14.67	8.29	8.87	2.44		0.87	375
400 425							L				15.64 16.62	9.34 10.45	9.46 10.05	2.75 3.07	1	0.98 1.10	400 425
425			represent								17.60	11.62	10.05	3.41	1	1.22	
475	Use wit	h cautior	n where wa	ater han	nmer is a o	concern.					18.58	12.84	11.23	3.77	7.36	1.35	475
500													11.82	4.15	7.74	1.48	500

					OSS FPS LOSS FPS LOS FPS LOSS														
N							P	SI Loss	• •	,			4" thru 4	, "					N a series a l
Nominal Size	3/	4 "	1	"	1	/4"	1	1/2"	2		2	/2"	3		31	⁄2"	4	"	Nominal Size
Pipe ID	0.			1.189							2.601		3.166				4.072		Pipe ID
Pipe OD Wall Thick	1.0		1.3														4.500 0.214		Pipe OD Wall Thick
vvan mick	0.0	/00	0.0	/00	0.0			50	0.1	10	0.	0.137		0.167		30	0.214		wai mick
Flow	Velocity	PSI	Velocity	PSI												PSI	Velocity	PSI	Flow
GPM 1	FPS 0.47	LOSS 0.06	FPS 0.29	0.02					FP5	L055	FP5	L055	FP5	L055	FP5	L055	FPS	LOSS	GPM 1
2	0.94	0.22	0.58	0.07	1		1												2
3	1.42 1.89	0.46 0.79	0.87 1.15	0.14 0.24	1		-				1								3 4
5	2.36	1.19	1.44	0.36	1						1								5
6 7	2.83 3.30	1.67 2.23	1.73 2.02	0.51	1		1				1		1						6 7
8	3.30	2.25	2.02	0.86	1		1				1								8
9	4.25	3.55	2.60	1.07	1		1				1		1			0.00			9
10	4.72 5.66	4.31 6.04	2.89 3.46	1.30		-							-			0.01	0.30	0.00	10 12
14	6.60	8.04	4.04	2.43	2.53	0.78	1.93	0.40	1.24	0.14	0.84	0.05	0.57	0.02	0.44	0.01	0.34	0.01	14
15 16	7.08 7.55	9.13 10.29	4.33 4.62	2.76			1				1					0.01	0.37 0.39	0.01 0.01	15 16
18	8.49	12.80	5.19	3.87	-		1				1		1			0.01	0.39	0.01	18
20	9.43	15.56	5.77	4.71			1				1		1			0.02	0.49	0.01	20
22 24	10.38 11.32	18.56 21.81	6.35 6.93	5.62 6.60							1		1			0.02 0.03	0.54 0.59	0.01 0.02	22 24
25	11.79	23.52	7.22	7.12	4.52	2.28	3.45	1.18	2.21	0.40	1.51	0.16	1.02	0.06	0.78	0.03	0.62	0.02	25
26 28	12.27 13.21	25.29 29.01	7.50 8.08	7.65	4.70 5.06	2.45 2.82	3.59 3.86	1.27	2.30 2.47	0.43	1.57 1.69	0.17	1.06	0.07	0.81	0.03	0.64	0.02	26 28
30	14.15	32.96	8.66	9.97	5.43	3.20	4.14	1.40	2.47	0.49	1.81	0.19	1.14	0.07	0.93	0.04	0.09	0.02	30
32	15.10	37.15	9.24	11.24	5.79	3.61	4.41	1.86	2.83	0.63	1.93	0.25	1.30	0.10	1.00	0.05	0.79	0.03	32
34 35	16.04 16.51	41.56 43.86	9.81 10.10	12.58 13.27	6.15 6.33	4.03 4.26	4.69 4.83	2.09 2.20	3.00 3.09	0.71 0.74	2.05	0.28 0.29	1.38 1.42	0.11 0.11	1.06 1.09	0.06 0.06	0.84 0.86	0.03 0.03	34 35
36	16.98	46.21	10.39	13.98	6.51	4.48	4.96	2.32	3.18	0.78	2.17	0.31	1.47	0.12	1.12	0.06	0.89	0.03	36
38 40	17.93 18.87	51.07 56.16	10.97 11.54	15.45 16.99	6.87 7.23	4.96 5.45	5.24 5.52	2.56 2.82	3.36 3.53	0.87 0.95	2.29 2.41	0.34 0.38	1.55 1.63	0.13 0.14	1.18 1.25	0.07 0.08	0.94 0.98	0.04 0.04	38 40
42	19.81	61.47	12.12	18.60	7.60	5.97	5.79	3.08	3.71	1.04	2.53	0.41	1.71	0.16	1.31	0.08	1.03	0.05	42
44	20.76	67.00	12.70 12.99	20.27 21.13	7.96 8.14	6.50 6.78	6.07 6.21	3.36 3.51	3.89 3.98	1.14	2.65	0.45	1.79 1.83	0.17	1.37 1.40	0.09	1.08	0.05	44 45
45			13.28	22.01	8.32	7.06	6.34	3.65	4.06	1.19	2.71	0.47	1.87	0.18	1.40	0.09	1.13	0.05	45
48			13.85	23.82	8.68	7.64	6.62	3.95	4.24	1.34	2.89	0.53	1.95	0.20	1.49	0.11	1.18	0.06	48
50 55			14.43 15.87	25.69 30.65	9.04 9.95	8.24 9.83	6.90 7.59	4.26 5.08	4.42 4.86	1.44 1.72	3.02 3.32	0.57 0.68	2.04 2.24	0.22 0.26	1.56 1.71	0.11 0.14	1.23 1.35	0.06 0.08	50 55
60			17.32	36.00	10.85	11.55	8.27	5.97	5.30	2.02	3.62	0.80	2.44	0.31	1.87	0.16	1.48	0.09	60
65 70			18.76	41.76	11.76 12.66	13.39 15.36	8.96 9.65	6.93 7.95	5.74 6.18	2.34 2.69	3.92 4.22	0.93 1.06	2.65 2.85	0.36 0.41	2.02 2.18	0.19 0.21	1.60 1.72	0.10 0.12	65 70
75					13.56	17.46	10.34	9.03	6.63	3.05	4.52	1.21	3.05	0.46	2.34	0.24	1.85	0.14	75
<u>80</u> 85					14.47 15.37	19.67 22.01	11.03 11.72	10.17 11.38	7.07	3.44	4.82 5.13	1.36	3.26 3.46	0.52	2.49 2.65	0.27	1.97 2.09	0.15	80 85
90					16.28	24.47	12.41	12.65	7.95	4.28	5.43	1.69	3.66	0.65	2.80	0.34	2.21	0.19	90
95					17.18	27.05	13.10	13.99	8.39	4.73	5.73	1.87	3.87	0.72	2.96	0.37	2.34	0.21	95
100 110					18.09 19.89	29.74 35.48	13.79 15.17	15.38 18.35	8.83 9.72	5.20 6.21	6.03 6.63	2.06 2.45	4.07 4.48	0.79 0.94	3.11 3.42	0.41 0.49	2.46 2.71	0.23 0.28	100 110
120							16.55	21.56	10.60	7.30	7.24	2.88	4.88	1.11	3.74	0.58	2.95	0.33	120
130 140							17.93 19.31	25.00 28.68	11.48 12.37	8.46 9.71	7.84 8.44	3.34 3.83	5.29 5.70	1.28 1.47	4.05 4.36	0.67 0.77	3.20 3.44	0.38 0.43	130 140
150							10.01	20.00	13.25	11.03	9.05	4.36	6.11	1.67	4.67	0.87	3.69	0.49	150
175									15.46	14.67	10.55	5.80	7.12	2.23	5.45	1.16	4.31	0.65	175
200 225									17.67 19.88	18.79 23.37	12.06 13.57	7.42 9.23	8.14 9.16	2.85 3.55	6.23 7.01	1.49 1.85	4.92 5.54	0.84	200 225
250											15.08	11.22	10.18	4.31	7.78	2.25	6.15	1.27	250
275 300											16.58 18.09	13.39 15.73	11.19 12.21	5.14 6.04	8.56 9.34	2.68 3.15	6.77 7.38	1.51 1.78	275 300
350													14.25	8.04	10.90	4.19	8.61	2.36	350
400 450													16.28	10.29 12.80	12.45	5.36	9.84	3.03	400
450 500													18.32	12.80	14.01 15.57	6.67 8.11	11.07 12.30	3.76 4.57	450 500
550	L S	haded a	rea repres	sents vel	ocities ov	er 5 FPS	<u> </u>								17.12	9.67	13.53	5.46	550
600 700	Use	with cau	ition wher	e water	hammer i	s a conce	ərn.								18.68	11.36	14.76 17.22	6.41 8.53	600 700
800																	19.68	10.92	800

			Γ		Cla				Charac PVC F		^{ics} tic P	ipe]			
					PS	SI Loss	• •	,	=150 Sl f Pipe		5 2" thru 3						
Nominal Size	14		3⁄4		1				•		2"		2½"			Nominal Size	
Pipe ID	1/2 0.7		0.8		1.121		1 ¼" 1.414		1½ " 1.618		2.0		2.4		3" 2.982		Pipe ID
Pipe OD	0.84		1.0		1.315		1.660		1.9		2.3		2.8		3.500		Pipe OD
Wall Thick	0.06	62	0.0	78	0.0	97	0.1	0.123		41	0.1	76	0.2	13	0.2	59	Wall Thick
Flow	Velocity	PSI	Velocity	PSI	Velocity	PSI	Velocity	PSI	Velocity	PSI	Velocity	PSI	Velocity	PSI	Velocity	PSI	Flow
GPM 1	FPS 0.80	LOSS 0.22	FPS 0.51	LOSS 0.07	FPS 0.32	LOSS 0.02	FPS 0.20	LOSS 0.01	FPS 0.16	LOSS 0.00	FPS	LOSS	FPS	LOSS	FPS	LOSS	GPM 1
2	1.59	0.78	1.02	0.27	0.65	0.09	0.41	0.03	0.31	0.01	0.20	0.00					2
3	2.39 3.18	1.65 2.82	1.53 2.04	0.56 0.96	0.97	0.19 0.32	0.61 0.82	0.06 0.10	0.47 0.62	0.03 0.05	0.30 0.40	0.01 0.02	0.20 0.27	0.00 0.01			3 4
5	3.98	4.26	2.55	1.45	1.62	0.32	1.02	0.16	0.78	0.03	0.50	0.02	0.27	0.01	0.23	0.00	5
6	4.78	5.97	3.06	2.03	1.95	0.67	1.22	0.22	0.94	0.11	0.60	0.04	0.41	0.02	0.28	0.01	6
7	5.57 6.37	7.95 10.18	3.57 4.08	2.70 3.45	2.27 2.60	0.90 1.15	1.43 1.63	0.29 0.37	1.09 1.25	0.15 0.19	0.70 0.80	0.05 0.06	0.48 0.54	0.02	0.32	0.01 0.01	7 8
9	7.16	12.66	4.59	4.30	2.92	1.43	1.84	0.46	1.40	0.24	0.90	0.08	0.61	0.03	0.41	0.01	9
10	7.96	15.38	5.10	5.22	3.25	1.74	2.04	0.56	1.56	0.29	1.00	0.10	0.68	0.04	0.46	0.01	10 11
12	8.75 9.55	18.35 21.56	5.62 6.13	6.23 7.32	3.57 3.90	2.07 2.43	2.24 2.45	0.67 0.79	1.71 1.87	0.35	1.10 1.20	0.12	0.75 0.82	0.05 0.05	0.50	0.02 0.02	12
13	10.35	25.01	6.64	8.49	4.22	2.82	2.65	0.91	2.03	0.47	1.30	0.16	0.88	0.06	0.60	0.02	13
14 15	11.14	28.69 32.60	7.15	9.74 11.07	4.55 4.87	3.24 3.68	2.86 3.06	1.05	2.18 2.34	0.54 0.62	1.40	0.18 0.21	0.95	0.07 0.08	0.64	0.03 0.03	14 15
16	11.94 12.73	36.73	7.66	12.47	5.19	4.15	3.06	1.19 1.34	2.34	0.02	1.50 1.60	0.21	1.02	0.08	0.69	0.03	15
17	13.53	41.10	8.68	13.95	5.52	4.64	3.47	1.50	2.65	0.78	1.69	0.26	1.16	0.10	0.78	0.04	17
18 19	14.33 15.12	45.69 50.50	9.19 9.70	15.51 17.14	5.84 6.17	5.16 5.70	3.67 3.88	1.67 1.84	2.81 2.96	0.86 0.96	1.79 1.89	0.29 0.32	1.22 1.29	0.12 0.13	0.83	0.04 0.05	18 19
20	15.12	55.53	10.21	17.14	6.49	6.27	4.08	2.03	2.90	1.05	1.89	0.32	1.29	0.13	0.87	0.05	20
22	17.51	66.25	11.23	22.49	7.14	7.48	4.49	2.42	3.43	1.25	2.19	0.42	1.50	0.17	1.01	0.06	22
24 25	19.10	77.84	12.25 12.76	26.42 28.50	7.79 8.12	8.79 9.48	4.90 5.10	2.84	3.74 3.90	1.47 1.59	2.39 2.49	0.50 0.54	1.63 1.70	0.20 0.21	1.10 1.15	0.08 0.08	24 25
25			13.27	30.65	8.44	10.19	5.31	3.29	4.05	1.59	2.49	0.54	1.70	0.21	1.19	0.08	25
28			14.29	35.15	9.09	11.69	5.71	3.78	4.36	1.96	2.79	0.66	1.90	0.26	1.28	0.10	28
30 32			15.31 16.34	39.95 45.02	9.74 10.39	13.28 14.97	6.12 6.53	4.29 4.84	4.68 4.99	2.23 2.51	2.99 3.19	0.75 0.85	2.04 2.18	0.30 0.33	1.38 1.47	0.11 0.13	30 32
34			17.36	50.37	11.04	16.75	6.94	5.41	5.30	2.81	3.39	0.05	2.31	0.37	1.56	0.13	34
35			17.87	53.14	11.36	17.67	7.14	5.71	5.45	2.96	3.49	1.00	2.38	0.39	1.61	0.15	35
36 38			18.38 19.40	55.99 61.89	11.69 12.34	18.62 20.58	7.35	6.02 6.65	5.61 5.92	3.12 3.45	3.59 3.79	1.05	2.45 2.59	0.42	1.65	0.16	36 38
40			10.40	01.00	12.99	22.63	8.16	7.31	6.23	3.79	3.99	1.28	2.72	0.50	1.84	0.19	40
42					13.64	24.77	8.57	8.00	6.55	4.15	4.19	1.40	2.86	0.55	1.93	0.21	42
44 45					14.29 14.61	27.00 28.15	8.98 9.18	8.72 9.09	6.86 7.01	4.53 4.72	4.39 4.49	1.53 1.59	2.99 3.06	0.60 0.63	2.02 2.06	0.23 0.24	44 45
46					14.94	29.32	9.39	9.47	7.17	4.92	4.59	1.66	3.13	0.65	2.11	0.24	46
48					15.58	31.72	9.79	10.25	7.48	5.32	4.79	1.79	3.27	0.71	2.20	0.27	48
50 55					16.23 17.86	34.21 40.82	10.20 11.22	11.05 13.19	7.79 8.57	5.74 6.84	4.98	1.93	3.40 3.74	0.76 0.91	2.29 2.52	0.29 0.35	50 55
60					19.48	47.95	12.24	15.49	9.35	8.04	5.98	2.71	4.08	1.07	2.75	0.00	60
65							13.26	17.97	10.13	9.33		3.14	4.42	1.24	2.98	0.48	65
70 75							14.28 15.30	20.61 23.42	10.91 11.69	10.70 12.16		3.61 4.10	4.76	1.42	3.21 3.44	0.55 0.62	70 75
80							16.32	26.39	12.47	13.70	7.98	4.62	5.44	1.82	3.67	0.02	80
85							17.35	29.53	13.25	15.33	8.47	5.17	5.78	2.04	3.90	0.78	85
90 95							18.37 19.39	32.83 36.28	14.03 14.81	17.04 18.83		5.75 6.35	6.12 6.46	2.27 2.51	4.13 4.36	0.87 0.96	90 95
100							. 5.00	00.20	15.58	20.71	9.97	6.98	6.80	2.76	4.59	1.06	100
110									17.14	24.71	10.97	8.33	7.48	3.29	5.05	1.26	110
120 130									18.70	29.03	11.96 12.96	9.79 11.35	8.16 8.84	3.86	5.51 5.96	1.48	120 130
140											13.96	13.02	9.52	5.14		1.97	140
150											14.95	14.80	10.20	5.84	6.88	2.24	150
175 200											17.45 19.94	19.69 25.21	11.90 13.61	7.77 9.95	8.03 9.18	2.98 3.82	175 200
225											10.04	20.21	15.31	12.37	10.32	4.75	225
250													17.01	15.04	11.47	5.77	250
275 300													18.71	17.94	12.62 13.76	6.88 8.09	275 300
325					ocities ove nammer is										14.91	9.38	325
350						2 001100									16.06	10.76	350
400															18.35	13.78	400

						edu	20) C=1	IPS	PV	C Pla	tics AStiC Feet of I		e				
Nominal				L				01203 /		,							Nominal
Size	1⁄2		3/4		1			/4"		/2"	2		21/		3		Size
Pipe ID	0.6		0.8		1.0		1.380		1.610		2.0		2.4		3.068		Pipe ID
Pipe OD	0.8		1.0		1.3		1.660 0.140		1.900		2.3		2.8		3.5		Pipe OD
Wall Thick	0.1	09	0.1	13	0.1	33	0.1	40	0.1	145	0.1	54	0.2	03	0.2	16	Wall Thick
Flow	Velocity	PSI	Velocity	PSI	Velocity	PSI	Velocity	PSI	Flow								
GPM	FPS	LOSS	FPS	LOSS	FPS	LOSS	FPS	LOSS	GPM								
1	1.05	0.43	0.60	0.11	0.37	0.03	0.21	0.01	0.16	0.00							1
2	2.11	1.55	1.20	0.39	0.74	0.12	0.43	0.03	0.31	0.02	0.19	0.00					2
3	3.16	3.28	1.80	0.84	1.11	0.26	0.64	0.07	0.47	0.03	0.29	0.01	0.20	0.00			3
4	4.22	5.59	2.40	1.42	1.48	0.44	0.86	0.12	0.63	0.05	0.38	0.02	0.27	0.01	0.00	0.00	4
5	5.27 6.33	8.45 11.85	3.00 3.61	2.15	1.85 2.22	0.66	1.07	0.17	0.79	0.08	0.48	0.02	0.33	0.01	0.22	0.00	5
7	7.38	15.76	4.21	4.01	2.60	1.24	1.50	0.33	1.10	0.15	0.67	0.05	0.40	0.02	0.20	0.01	7
8	8.44	20.18	4.81	5.14	2.97	1.59	1.71	0.42	1.26	0.20	0.76	0.06	0.54	0.02	0.35	0.01	8
9	9.49	25.10	5.41	6.39	3.34	1.97	1.93	0.52	1.42	0.25	0.86	0.07	0.60	0.03	0.39	0.01	9
10	10.55	30.51	6.01	7.77	3.71	2.40	2.14	0.63	1.57	0.30	0.95	0.09	0.67	0.04	0.43	0.01	10
11	11.60	36.40	6.61	9.26	4.08	2.86	2.36	0.75	1.73	0.36	1.05	0.11	0.74	0.04	0.48	0.02	11
12	12.65	42.77	7.21	10.88	4.45	3.36	2.57	0.89	1.89	0.42	1.15	0.12	0.80	0.05	0.52	0.02	12
13	13.71	49.60	7.81	12.62	4.82	3.90	2.79	1.03	2.05	0.48	1.24	0.14	0.87	0.06	0.56	0.02	13
14 15	14.76	56.90 64.65	8.41 9.01	14.48	5.19	4.47 5.09	3.00	1.18 1.34	2.20 2.36	0.56 0.63	1.34	0.16 0.19	0.94 1.00	0.07 0.08	0.61	0.02 0.03	14 15
15	15.82 16.87	64.65 72.86	9.01	16.45 18.54	5.56 5.93	5.08 5.73	3.21 3.43	1.34	2.36	0.63	1.43 1.53	0.19	1.00	0.08	0.65	0.03	15
17	17.93	81.52	10.22	20.75	6.30	5.73 6.41	3.64	1.69	2.52	0.71	1.62	0.21	1.14	0.09	0.89	0.03	17
18	18.98	90.62	10.82	23.06	6.67	7.12	3.86	1.88	2.83	0.89	1.72	0.26	1.20	0.11	0.78	0.04	18
19			11.42	25.49	7.04	7.87	4.07	2.07	2.99	0.98	1.81	0.29	1.27	0.12	0.82	0.04	19
20			12.02	28.03	7.42	8.66	4.28	2.28	3.15	1.08	1.91	0.32	1.34	0.13	0.87	0.05	20
22			13.22	33.44	8.16	10.33	4.71	2.72	3.46	1.28	2.10	0.38	1.47	0.16	0.95	0.06	22
24			14.42	39.29	8.90	12.14	5.14	3.20	3.78	1.51	2.29	0.45	1.61	0.19	1.04	0.07	24
25			15.02	42.38	9.27	13.09	5.36	3.45	3.94	1.63	2.39	0.48	1.67	0.20	1.08	0.07	25
26 28			15.62	45.57 52.27	9.64	14.08 16.15	5.57	3.71 4.25	4.09	1.75 2.01	2.48 2.67	0.52 0.60	1.74 1.87	0.22 0.25	1.13	0.08 0.09	26 28
30			16.83 18.03	59.40	10.38	18.35	6.00 6.43	4.25	4.41 4.72	2.01	2.86	0.60	2.01	0.25	1.21 1.30	0.09	30
32			19.23	66.94	11.86	20.68	6.86	5.44	5.04	2.57	3.06	0.76	2.01	0.32	1.39	0.10	32
34			10.20		12.61	23.13	7.28	6.09	5.35	2.88	3.25	0.85	2.28	0.36	1.47	0.12	34
35					12.98	24.41	7.50	6.43	5.51	3.04	3.34	0.90	2.34	0.38	1.52	0.13	35
36					13.35	25.72	7.71	6.77	5.67	3.20	3.44	0.95	2.41	0.40	1.56	0.14	36
38					14.09	28.43	8.14	7.48	5.98	3.54	3.63	1.05	2.54	0.44	1.65	0.15	38
40					14.83	31.26	8.57	8.23	6.30	3.89	3.82	1.15	2.68	0.49	1.73	0.17	40
42					15.57	34.22	9.00	9.01	6.61	4.25	4.01	1.26	2.81	0.53	1.82	0.18	42
44 45					16.31 16.68	37.29 38.88	9.43 9.64	9.82 10.24	6.93 7.08	4.64 4.83	4.20 4.30	1.37 1.43	2.94 3.01	0.58 0.60	1.91 1.95	0.20 0.21	44 45
46					17.06	40.49	9.86	10.24	7.24	5.04	4.39	1.49	3.08	0.63	1.99	0.21	46
48					17.80	43.81	10.28	11.54	7.56	5.45	4.58	1.62	3.21	0.68	2.08	0.24	48
50					18.54	47.26	10.71	12.44	7.87	5.88	4.77	1.74	3.35	0.73	2.17	0.25	50
55							11.78	14.84	8.66	7.01	5.25	2.08	3.68	0.88	2.38	0.30	55
60							12.85	17.44	9.44	8.24	5.73	2.44	4.02	1.03	2.60	0.36	60
65							13.93	20.23	10.23	9.55	6.21	2.83	4.35	1.19	2.82	0.41	65
70 75							15.00	23.20	11.02	10.96	6.68	3.25	4.69	1.37	3.03	0.48	70
75 80							16.07 17.14	26.36 29.71	11.81 12.59	12.45 14.03	7.16 7.64	3.69 4.16	5.02 5.35	1.55 1.75	3.25 3.47	0.54 0.61	75 80
85							18.21	33.24	13.38	15.70	8.12	4.10	5.69	1.96	3.68	0.68	85
90			<u> </u>				19.28	36.95	14.17	17.45	8.59	5.17	6.02	2.18	3.90	0.76	90
95									14.95	19.29	9.07	5.72	6.36	2.41	4.12	0.84	95
100									15.74	21.21	9.55	6.29	6.69	2.65	4.33	0.92	100
110									17.31	25.31	10.50	7.50	7.36	3.16	4.77	1.10	110
120									18.89	29.74	11.46	8.82	8.03	3.71	5.20	1.29	120
130 140											12.41	10.22	8.70	4.31	5.63	1.50	130
140 150											13.37 14.32	11.73 13.33	9.37 10.04	4.94 5.61	6.07 6.50	1.72 1.95	140 150
160											15.28	15.02	10.71	6.33	6.94	2.20	160
170											16.23	16.80	11.38	7.08	7.37	2.46	170
180											17.19	18.68	12.05	7.87	7.80	2.73	180
190											18.14	20.65	12.72	8.70	8.24	3.02	190
200											19.10	22.70	13.39	9.56	8.67	3.32	200
225													15.06	11.89	9.75	4.13	225
250													16.73	14.46	10.84	5.02	250
275													18.41	17.25	11.92	5.99	275
300 325	s	haded a	rea repre	sents ve	locities ov	er 5 FP	s.								13.00 14.09	7.04 8.17	300 325
325			ution whe												15.17	9.37	325
375															16.25	10.64	375
400															17.34	12.00	400

					Friction Loss Characteristics Schedule 40 Standard Steel Pipe C=100 Sizes ½" thru 3" PSI Loss Per 100 Feet of Pipe												
Nominal Size Pipe ID Pipe OD Wall Thick	1½ 0.62 0.84 0.10	22 40	³ ⁄4" 0.824 1.050 0.113		1" 1.049 1.315 0.133		11/4 " 1.380 1.660 0.140		11/2" 1.610 1.900 0.145		2" 2.067 2.375 0.154		2½" 2.469 2.875 0.203		3' 3.06 3.50 0.2	58 00	Nominal Size Pipe ID Pipe OD Wall Thick
Flow GPM	Velocity FPS	PSI LOSS	Velocity FPS	PSI LOSS	Velocity FPS	PSI LOSS	Velocity FPS	PSI LOSS	Velocity FPS	PSI LOSS	Velocity FPS	PSI LOSS	Velocity FPS	PSI LOSS	Velocity FPS	PSI LOSS	Flow GPM
1	1.05	0.91	0.60	0.23	0.37	0.07	0.21	0.02	0.16	0.01	0.10	0.00			110	2000	1
2 3	2.11 3.16	3.28 6.95	1.20 1.80	0.84 1.77	0.74 1.11	0.26 0.55	0.43 0.64	0.07 0.14	0.31 0.47	0.03 0.07	0.19 0.29	0.01 0.02	0.13 0.20	0.00 0.01	0.13	0.00	2 3
4	4.22	11.85	2.40	3.02	1.48	0.93	0.86	0.25	0.63	0.12	0.38	0.03	0.27	0.01	0.17	0.01	4
5	5.27 6.33	17.91 25.10	3.00	4.56	1.85 2.22	<u>1.41</u> 1.97	1.07	0.37	0.79	0.18	0.48	0.05	0.33	0.02	0.22	0.01	5
7	7.38	33.40	4.21	8.50	2.60	2.63	1.50	0.69	1.10	0.33	0.67	0.10	0.47	0.04	0.30	0.01	7
8 9	8.44 9.49	42.77	4.81	10.88 13.54	2.97 3.34	3.36	1.71 1.93	0.89	1.26 1.42	0.42 0.52	0.76 0.86	0.12 0.15	0.54	0.05	0.35	0.02 0.02	8
9 10	9.49	53.19 64.65	6.01	13.54	3.34	4.18 5.08	2.14	1.10 1.34	1.42	0.52	0.86	0.15	0.60 0.67	0.06 0.08	0.39 0.43	0.02	10
11	11.60	77.14	6.61	19.63	4.08	6.06	2.36	1.60	1.73	0.75	1.05	0.22	0.74	0.09	0.48	0.03	11
12	12.65	90.62	7.21	23.06	4.45	7.12	2.57	1.88	1.89	0.89	1.15	0.26	0.80	0.11	0.52	0.04	12
13 14	13.71 14.76	105.1 120.6	7.81	26.75 30.68	4.82 5.19	8.26 9.48	2.79 3.00	2.18 2.50	2.05 2.20	1.03 1.18	1.24 1.34	0.30 0.35	0.87 0.94	0.13 0.15	0.56 0.61	0.04 0.05	13 14
15	15.82	137.0	9.01	34.87	5.56	10.77	3.21	2.84	2.36	1.34	1.43	0.40	1.00	0.17	0.65	0.06	15
16	16.87	154.4	9.61	39.29	5.93	12.14	3.43	3.20	2.52	1.51	1.53	0.45	1.07	0.19	0.69	0.07	16
17 18	17.93 18.98	172.7 192.0	10.22 10.82	43.96 48.87	6.30 6.67	13.58 15.10	3.64 3.86	3.58 3.97	2.68 2.83	1.69 1.88	1.62 1.72	0.50 0.56	1.14 1.20	0.21 0.23	0.74 0.78	0.07 0.08	17 18
19			11.42	54.02	7.04	16.69	4.07	4.39	2.99	2.07	1.81	0.62	1.27	0.26	0.82	0.09	19
20			12.02	59.40	7.42	18.35	4.28	4.83	3.15	2.28	1.91	0.68	1.34	0.28	0.87	0.10	20
22 24			13.22 14.42	70.87 83.26	8.16 8.90	21.89 25.72	4.71 5.14	5.76 6.77	3.46 3.78	2.72 3.20	2.10 2.29	0.81 0.95	1.47 1.61	0.34 0.40	0.95 1.04	0.12 0.14	22 24
25			15.02	89.80	9.27	27.74	5.36	7.30	3.94	3.45	2.39	1.02	1.67	0.43	1.08	0.15	25
26			15.62	96.56	9.64	29.83	5.57	7.85	4.09	3.71	2.48	1.10	1.74	0.46	1.13	0.16	26
28 30			16.83 18.03	110.8 125.9	10.38 11.12	34.22 38.88	6.00 6.43	9.01 10.24	4.41	4.25	2.67 2.86	1.26	1.87 2.01	0.53	1.21 1.30	0.18	28 30
32			10.00		11.86	43.81	6.86	11.54	5.04	5.45	3.06	1.62	2.14	0.68	1.39	0.24	32
34					12.61	49.02	7.28	12.91	5.35	6.10	3.25	1.81	2.28	0.76	1.47	0.26	34
35 36					12.98 13.35	51.72 54.49	7.50 7.71	13.62 14.35	5.51 5.67	6.43 6.78	3.34 3.44	1.91 2.01	2.34 2.41	0.80 0.85	1.52 1.56	0.28 0.29	35 36
38					14.09	60.23	8.14	15.86	5.98	7.49	3.63	2.22	2.54	0.94	1.65	0.33	38
40					14.83	66.24	8.57	17.44	6.30	8.24	3.82	2.44	2.68	1.03	1.73	0.36	40
42 44					15.57 16.31	72.50 79.02	9.00 9.43	19.09 20.81	6.61 6.93	9.02 9.83	4.01 4.20	2.67 2.91	2.81 2.94	1.13 1.23	1.82 1.91	0.39 0.43	42 44
45					16.68	82.38	9.64	21.69	7.08	10.25	4.30	3.04	3.01	1.28	1.95	0.44	45
46					17.06	85.80	9.86	22.59	7.24	10.67	4.39	3.16	3.08	1.33	1.99	0.46	46
48 50					17.80 18.54	92.84 100.1	10.28 10.71	24.44 26.36	7.56 7.87	11.55 12.45	4.58 4.77	3.42 3.69	3.21 3.35	1.44 1.55	2.08 2.17	0.50 0.54	48 50
55							11.78	31.45	8.66	14.86	5.25	4.40	3.68	1.85	2.38	0.64	55
60							12.85	36.95	9.44	17.45	5.73	5.17	4.02	2.18	2.60	0.76	60
65 70							13.93 15.00	42.86 49.16	10.23 11.02	20.24 23.22	6.21 6.68	6.00 6.88	4.35 4.69	2.53 2.90	2.82 3.03	0.88 1.01	65 70
75							16.07	55.86	11.81	26.39	7.16	7.82	5.02	3.29	3.25	1.14	75
80							17.14	62.96		29.74 33.27	7.64	8.82 9.86	5.35	3.71 4.15	3.47	1.29	80 85
85 90							18.21	70.44	13.38 14.17	36.98	8.12 8.59	9.86	5.69 6.02	4.15	3.68 3.90	1.44 1.60	90
95									14.95	40.88	9.07	12.12	6.36	5.10	4.12	1.77	95
100 110									15.74	44.95	9.55	13.33	6.69 7.36	5.61	4.33	1.95	100
110 120									17.31 18.89	53.63 63.01	10.50 11.46	15.90 18.68	7.36 8.03	6.70 7.87	4.77 5.20	2.33 2.73	110 120
130											12.41	21.66	8.70	9.12	5.63	3.17	130
140											13.37	24.85	9.37	10.47	6.07	3.64	140
150 160											14.32 15.28	28.24 31.82	10.04 10.71	11.89 13.40	6.50 6.94	4.13 4.66	150 160
170											16.23	35.61	11.38	15.00	7.37	5.21	170
180											17.19	39.58	12.05	16.67	7.80	5.79	180
190 200											18.14	43.75	12.72 13.39	18.43 20.26	8.24 8.67	6.40 7.04	190 200
225													15.06	25.20	9.75	8.76	225
250													16.73	30.63	10.84	10.64	250
275 300							L,						18.41	36.54	11.92 13.00	12.70 14.92	275 300
300					cities over		_								14.09	14.92	325
350	Use	witri cau	uon where	water h	ammer is a	a concer									15.17	19.85	350
375															16.25	22.56	375
400															17.34	25.42	400

Friction Loss Characteristics Polyethylene (PE) Pipe - SDR Pressure Rated Tube C=140 SDR 7, 9, 11.5, 15 Sizes ½" thru 2" PSI Loss Per 100 Feet of Pipe

L Nominal													Nominal
Size	1/2	2"	3/4	"	1	"	11	4"	11	2"	2	Size	
Pipe ID	0.6	22	0.824		1.049		1.3	80	1.6		2.0	67	Pipe ID
Flow	Velocity	PSI	Velocity	PSI	Velocity	PSI	Velocity	PSI	Velocity	PSI	Velocity	PSI	Flow
GPM	FPS	LOSS	FPS	LOSS	FPS	LOSS	FPS	LOSS	FPS	LOSS	FPS	LOSS	GPM
1	1.05	0.49	0.60	0.12	0.37	0.04	0.21	0.01	0.16	0.00	0.10	0.00	1
2	2.11	1.76	1.20	0.45	0.74	0.14	0.43	0.04	0.31	0.02	0.19	0.01	2
3	3.16	3.73	1.80	0.95	1.11	0.29	0.64	0.08	0.47	0.04	0.29	0.01	3
4	4.22	6.35	2.40	1.62	1.48	0.50	0.86	0.13	0.63	0.06	0.38	0.02	4
5 6	5.27 6.33	9.60 13.46	3.00 3.61	2.44 3.43	1.85 2.22	0.76	1.07 1.29	0.20	0.79 0.94	0.09	0.48	0.03	5 6
7	7.38	17.91	4.21	3.43 4.56	2.22	1.41	1.29	0.20	1.10	0.13	0.57	0.04	7
8	8.44	22.93	4.81	5.84	2.97	1.80	1.71	0.47	1.26	0.22	0.76	0.07	8
9	9.49	28.52	5.41	7.26	3.34	2.24	1.93	0.59	1.42	0.28	0.86	0.08	9
10	10.55	34.67	6.01	8.82	3.71	2.73	2.14	0.72	1.57	0.34	0.95	0.10	10
11	11.60	41.36	6.61	10.53	4.08	3.25	2.36	0.86	1.73	0.40	1.05	0.12	11
12	12.65	48.60	7.21	12.37	4.45	3.82	2.57	1.01	1.89	0.48	1.15	0.14	12
13	13.71	56.36	7.81	14.34	4.82	4.43	2.79	1.17	2.05	0.55	1.24	0.16	13
14	14.76	64.65	8.41	16.45	5.19	5.08	3.00	1.34	2.20	0.63	1.34	0.19	14
15	15.82 16.87	73.47 82.79	9.01 9.61	18.70 21.07	5.56	5.78 6.51	3.21	1.52 1.71	2.36 2.52	0.72	1.43 1.53	0.21	15 16
16 17	17.93	92.63	10.22	23.57	5.93 6.30	7.28	3.43 3.64	1.92	2.52	0.81 0.91	1.62	0.24	17
18	18.98	103.0	10.82	26.21	6.67	8.10	3.86	2.13	2.83	1.01	1.72	0.30	18
19	10.00	10010	11.42	28.97	7.04	8.95	4.07	2.36	2.99	1.11	1.81	0.33	19
20			12.02	31.85	7.42	9.84	4.28	2.59	3.15	1.22	1.91	0.36	20
22			13.22	38.00	8.16	11.74	4.71	3.09	3.46	1.46	2.10	0.43	22
24			14.42	44.65	8.90	13.79	5.14	3.63	3.78	1.72	2.29	0.51	24
25			15.02	48.15	9.27	14.87	5.36	3.92	3.94	1.85	2.39	0.55	25
26			15.62	51.78	9.64	16.00	5.57	4.21	4.09	1.99	2.48	0.59	26
28			16.83	59.40	10.38	18.35	6.00	4.83	4.41	2.28	2.67	0.68	28
30 32			18.03 19.23	67.50 76.06	11.12 11.86	20.85 23.50	6.43 6.86	5.49 6.19	4.72 5.04	2.59 2.92	2.86 3.06	0.77 0.87	30 32
34			19.20	70.00	12.61	26.29	7.28	6.92	5.35	3.27	3.25	0.97	34
35					12.98	27.74	7.50	7.30	5.51	3.45	3.34	1.02	35
36					13.35	29.22	7.71	7.69	5.67	3.63	3.44	1.08	36
38					14.09	32.30	8.14	8.50	5.98	4.02	3.63	1.19	38
40					14.83	35.52	8.57	9.35	6.30	4.42	3.82	1.31	40
42					15.57	38.88	9.00	10.24	6.61	4.83	4.01	1.43	42
44					16.31	42.38	9.43	11.16	6.93	5.27	4.20	1.56	44
45					16.68	44.18	9.64	11.63	7.08	5.49	4.30	1.63	45
46 48					17.06 17.80	46.01 49.79	9.86 10.28	12.12 13.11	7.24 7.56	5.72 6.19	4.39 4.58	1.70 1.84	46 48
50					18.54	49.79 53.70	10.28	14.14	7.87	6.68	4.56	1.98	48 50
55					10.04	50.70	11.78	16.87	8.66	7.97	5.25	2.36	55
60							12.85	19.82	9.44	9.36	5.73	2.77	60
65							13.93	22.98	10.23	10.86	6.21	3.22	65
70							15.00	26.36	11.02	12.45	6.68	3.69	70
75							16.07	29.96	11.81	14.15	7.16	4.19	75
80							17.14	33.76	12.59	15.95	7.64	4.73	80
85							18.21	37.77	13.38	17.84	8.12	5.29	85
90 95							19.28	41.99	14.17 14.95	19.83 21.92	8.59 9.07	5.88 6.50	90 95
100									14.95	21.92	9.07	0.50 7.15	100
110									17.31	28.76	10.50	8.53	110
120									18.89	33.79	11.46	10.02	120
130											12.41	11.62	130
140	Ch	adod or	ea repres	onte vol		or 5 EDO	<u> </u>				13.37	13.33	140
150	1 1		ea repres tion where								14.32	15.14	150
160						~ 501100					15.28	17.07	160
170											16.23	19.09	170
180											17.19 18.14	21.23 23.46	180 190
190 200											18.14	23.46 25.80	200
200											19.10	20.00	200

Index

С

C factor, 14, 17 C=150, 17 Class-rated pipes, 17

D

Dynamic pressure, 8, 12, 21, 36

Е

Elevation change, 5, 7, 8, 20

F

Factors affecting flow, 23 Feet of head, 3, 5 Flow, 23, 41 Friction loss charts, 16, 46 Friction loss in pipe, 12, 16, 41, 46

G

GPM, 12

H

Hazen-Williams formula, 15 Hydraulics, 2

I

Inside Diameter (I.D.), 12, 13, 17 IPS (Iron Pipe Size), 16

L

Length, 12, 15

Ν

Nominal pipe size, 17 Number of outlets, 30

0

Outside Diameter (O.D.), 17

P

Pitot tube, 30 Pressure, 3 Pressure loss, 23, 33, 39 Pressure loss charts, 16 Pressure loss in fittings, 20, 40 Pressure losses, 12, 20, 30 PSI, 3, 5, 23, 30, 34 PSI loss, 17, 25

R

Roughness, 12, 14 Roughness factor, 15

S

Sample problems, 10, 19, 21, 36 Schedule-rated pipes, 17 SDR (Standard Dimension Ratio), 17 Static pressure, 8, 10, 41 Summary, 40

Т

Technical charts, 16, 46

V

Velocity, 12, 13, 17, 23, 41 Velocity head, 26, 41

W

Wall thickness, 21 Water flow, 27 Water movement, 16 Water pressure, 7 Weight of water, 8

 Hunter Industries Incorporated • The Irrigation Innovators
 © 2006 Hur

 U.S.A.: 1940 Diamond Street • San Marcos, California 92078 • TEL: (1) 760-744-5240 • FAX: (1) 760-744-7461 • www.HunterIndustries.com
 ©

 Europe: Båt. A2 - Europarc de Pichaury • 1330, rue Guillibert de la Lauzières • 13856 Aix-en-Provence Cedex 3, France • TEL: +33 (0) 442-37-16-90 • FAX: +33 (0) 442-39-89-71
 Australia: 8 The Parade West • Kent Town, South Australia 5067 • TEL: (61) 8-8363-3599 • FAX: (61) 8-8363-3687
 ED-002.8

© 2006 Hunter Industries Incorporated

11/06